


TRIPLE DRESSER

Assembly Instruction

A. Components :
1. Triple Dresser

Qty
1x



a



b



c



d



e

B. Hardware :

a. Screw ø8 x 2"

Qty

1 x

b. Screw ø8 x 5/8"

1 x

c. Restrain Strap


1 x

d. Metal Tabs

2 x

e. Plastic Wall Anchor

1 x



⚠ WARNING

Serious or fatal crushing injuries can occur from furniture tipover. To help prevent tip-over :

- Install tipover restraint provided.
 - Place heaviest items in the lowest drawers.
 - Unless specifically designed to accommodate, do not set Tv's or other heavy objects on top of this product.
 - Never allow children to climb or hang on drawers, doors or shelves.
 - Never open more than one drawer at a time.
- (OR)
- Do not defeat or remove the drawer interlock system.

Use of tip over restraints may only reduce, but not eliminate the risk of tip-over.

This is a permanent label. Do not attempt to remove.