














ASSEMBLY INSTRUCTIONS

<p>A</p> 	<p>B</p> 	<p>C</p>  <p>x2 chair front feet</p>	<p>D</p>  <p>x2 back leg with adjustable screws</p>	<p>E</p>  <p>x24</p>	<p>F</p>  <p>x2</p>	<p>G</p>  <p>x24</p> <p>H</p>  <p>x2</p>	<p>I</p>  <p>x1</p>	<p>J</p> 	<p>K</p>  <p>x4 Ottoman feet</p>
--	--	---	--	---	--	--	--	--	---


1.




2.



3.



4.





Adjust the screw to solve wobbly problem.

100%



5. Turn the bottom of the product up.



6. Finish.

