

Chair Assembly Instructions

Estimated Assembly Time in Minutes

☆ <15 ★ <45 ☆ 60+



Your Chair comes packaged in one box.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.

Parts List		Hardware List	
* ① 2 x Back legs		* ① 8 x Long Bolts	M6 x 35mm
* ② 2 x Front Legs		* ② 4 x Short Bolts	M6 x 30mm
③ 1 x Seat		* ③ 12 x Lock Washers	M6
④ 1 x Back		* ④ 8 x Large Flat Washers	M6 x 16mm
		* ⑤ 1 x Hex Key	M4 x 110mm
		* ⑥ 4 x Small Flat Washers	M6 x 12mm
		* ⑦ 4 x Wood Button	
		* Replaceable Parts	

Assembly

Step 1

Step 2

Step 3

Warning: Do not fully tightened until all legs are installed.

Step 4

Your chair style may differ from images. Care for your furniture by periodically tightening all bolts using the included hex key.

CAUTION: Tighten all components securely before use. Failure to do so may result in personal injury.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.