


ASSEMBLY INSTRUCTIONS


A	1 PC	B1	1 PC	B2	1 PC	C	4 PCS	D	1 PC	E-L	1 PC	E-R	1 PC
F-L	1 PC	F-R	1 PC	G	2 PCS	H	1 PC	I	1 PC	J	4 PCS	K	1 PC
L	1 PC	M	1 PC	N	1 PC	O	1 PC	P	1 PC	Q	1 PC	R	1 PC

M8*100		M8*15		M8*35		M8*70		M10*25		M10	
Q1	1 PC	Q2	2 PCS	Q3	4 PCS	Q4	1 PC	Q5	5 PCS	R1	1 PC
M8		M8		M8		M8		M8		M10	
R2	2 PCS	R3	1 PC	S1	10 PCS	S2	5 PCS	T1	1 PC	T2	5 PCS
M8		M8		M8		M8		M10		M10	
U	3 PCS	V	4 PCS	W	1 PC	X	2 PCS	Y	1 PC	Z	2 PCS




ASSEMBLY INSTRUCTIONS

③




④




⑤

When installing this tube, tighten the screws after the tube is straightened.




ASSEMBLY INSTRUCTIONS


⑥




⑦



⑧




⑨




ASSEMBLY INSTRUCTIONS


10




11



12



13



ASSEMBLY INSTRUCTIONS

14

