









# ASSEMBLY INSTRUCTION


ITEM NO.:F8437/ F8438




NO	DRAWING	QTY
A	 <b>Seat</b>	1
B	 <b>Back Cushion</b>	1
C	 <b>Metal Leg</b>	4

NO	DRAWING	QTY
D	 <b>Flat Washer</b>	8
E	 <b>Spring Washer</b>	8
F	 <b>Bolt</b>	8
G	 <b>Allen key</b>	1


Legs and hardware are stored at the bottom of the unit as shown with arrow sticker. Please take out the bun feet for assembly.



Step#1



Step#2



Step#3

