


Computer Desk

User Manual



AJ-DJ505115



Please read this instruction manual carefully before using the product

Package Contents


Plates and iron components

Assembly tool kit


Instruction manual




Package Contents




1. Avoid long-term direct sunlight exposure




2. Stay away from fire




3. keep away from sharp objects




4. Keep infants/children away from assembly parts to avoid choking and suffocation.




5. keep away from corrosive substances



6. Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.



7. Prevent objects from being damaged by immersion in water




8. Prevent object collision and damage



9. Be careful to avoid collisions


Installation of Cams and Pins

Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening o the hole of the pin it is locking. Lock the cam by tturning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.




Installation of Cams and Pins


1. Matters needing attention



Be sure to use the proper screws to avoid damaging the parts



Wrong screws can cause the plank to crack




The right screw is the right size


Matters needing attention

- (1) When installing the screws in the installation step, the screws do not need to be tightened. After this installation step is confirmed and the holes are aligned, then tighten all the screws.
- (2) If the screws are tightened during the installation process, it will cause problems such as misalignment of the screw holes and misalignment of the board in subsequent installations.

example




Do not tighten the screws




Screw down

Disassembly Diagram




















To our customer:



















Thank you for your purchase! Your order was shipped in 2 separate boxes (Box A and Box B). If you received only one box, please don't worry — the other is on the way.






Parts List Box-A

1X1 	2X1 	3X2 
4X1 	5X1 	6X1 
7X1 	8X2 Reverse side 	9X1 
10X1 	13X1 	14X1 
18X1 Reverse side 	19X1 Reverse side 	20X1 Reverse side 
21X1 	22X1 	23X1 

Parts List Box-A


24X1 	25X1 	26X1 
27X2 	28X4 	29X2 
33X2 	34X2 	35X2 
36X2 	37X2 	38X1 
41X1 	42X1 	43X2 
44X1 	45X2 	46X1 

Hardware list Box-A


A X85+3  ST6*40mm	B X85+3  Ø15*9.5mm	C X18+1  M6*40mm	D X50+2  ST5*40mm
F X48+4  Ø6*35mm	G X2  X4+1  X1 ST3*12mm	H X4 	I X5  M4*96mm
J X8  M4*16mm	K X2  M4*18mm	L X24+4  ST3.5*12mm	M X1  Ø53
N X28+4  ST3.5*14mm	O X22+1 	P X2 	Q X2 
X110  Ø21 x 0.3mm	X1 	X1  4#	X1  3#

Parts List Box-B


11X2




12X1




15X1




16X1




17X1




30X2




31X1




32X1



39X1



40X1




ASSEMBLY INSTRUCTION

STEP 1


D X4


ST5*40



Pay attention to the orientation of the holes

STEP 2


A X2

ST6*40




Pay attention to the orientation of the holes

ASSEMBLY INSTRUCTION

STEP 3



A X5




ST6*40


F X2



Ø6*35



STEP 4



A X5




ST6*40


F X2




Ø6*35



STEP 5



A X3




ST6*40


F X2




Ø6*35




STEP 6



A X2



ST6*40






ASSEMBLY INSTRUCTION

STEP 7

F X18


Ø6*35



STEP 8

B X3


Ø15*9.5



STEP 9

B X3

Ø15*9.5




ASSEMBLY INSTRUCTION

STEP 10

B X3



Ø15*9.5




STEP 12

B X2



Ø15*9.5



STEP 13




Pay attention to the orientation of the holes

D X4





ST5*40





ASSEMBLY INSTRUCTION

STEP 13





A X8
ST6*40

STEP 14



B X4
Ø15*9.5


STEP 15



B X4
Ø15*9.5

ASSEMBLY INSTRUCTION

STEP 16




A X8



ST6*40


STEP 17



B X8





Ø15*9.5





ASSEMBLY INSTRUCTION



STEP 18



STEP 19




STEP 20



Pay attention to the orientation of the holes

ASSEMBLY INSTRUCTION

STEP 21




C X9
M6*40




Pay attention to the orientation of the holes

STEP 22




A X2
ST6*40




ASSEMBLY INSTRUCTION

STEP 23





Disconnect the keyboard rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.

L X6
ST3.5*12



Disconnect the keyboard rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.





ASSEMBLY INSTRUCTION

STEP 24




L X6

ST3.5*12

Disconnect the keyboard rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.




Disconnect the keyboard rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.




ASSEMBLY INSTRUCTION


STEP 25



D X8
ST5*40





STEP 26



A X4
ST6*40

ASSEMBLY INSTRUCTION


STEP 27




Pay attention to the orientation of the holes

B X4

Ø15*9.5




STEP 28




ASSEMBLY INSTRUCTION

STEP 29





STEP 30



ASSEMBLY INSTRUCTION


STEP 31



B X10




Ø15*9.5



Pay attention to the orientation of the holes

ASSEMBLY INSTRUCTION

STEP 32




M X1



Ø53

STEP 33



N X2



ST3.5*14




N




N

44




ASSEMBLY INSTRUCTION

STEP 34




STEP 35




ASSEMBLY INSTRUCTION

STEP 36




STEP 37




ASSEMBLY INSTRUCTION

STEP 38



Until the 42 part is fully installed,
Please lock the B  screw.

STEP 39






D X4




ST5*40

ASSEMBLY INSTRUCTION

STEP 40




STEP 41




ASSEMBLY INSTRUCTION

STEP 42




Please do not lock the B screw.

STEP 43





Until the 37 part is fully installed,
Please lock the B screw.





ASSEMBLY INSTRUCTION

STEP 44




STEP 45




ASSEMBLY INSTRUCTION

STEP 46




STEP 47




ASSEMBLY INSTRUCTION

STEP 48



A X6
ST6*40


STEP 49



F X4
Ø6*35

ASSEMBLY INSTRUCTION


STEP 50




B X6



Ø15*9.5




STEP 51



D X4




ST5*40




Pay attention to the orientation of the holes

ASSEMBLY INSTRUCTION

STEP 52




STEP 53





D X4
ST5*40

ASSEMBLY INSTRUCTION

STEP 54




STEP 55



ASSEMBLY INSTRUCTION


STEP 56



Pay attention to the orientation of the holes

D X4
ST5*40

STEP 57









F X2
Ø6*35

D X4
ST5*40

ASSEMBLY INSTRUCTION


STEP 58

G X8	G X2	A X11
		
ST3*12		ST6*40




ASSEMBLY INSTRUCTION


STEP 59




1



2



Pay attention to the orientation of the holes



B X11



Ø15*9.5

STEP 60

J X4




M4*16

I X2




M4*96

H X4




ASSEMBLY INSTRUCTION

STEP 61





STEP 62



ASSEMBLY INSTRUCTION

STEP 63

A X7

ST6*40



ASSEMBLY INSTRUCTION

STEP 64

X110




Ø21 x 0.3

B X7



Ø15*9.5





ASSEMBLY INSTRUCTION

STEP 65

N X22

ST3.5*14

O X22



ASSEMBLY INSTRUCTION

STEP 66

P X2



Q X2



N X4




ST3.5*14


D X2



ST5*40



Customer Service



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us and we will get back to you within 24 hours
	Having issue(s) while reading the instruction or completing the assembly.	Feel free to contact us and we will get back to you within 24 hours.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Table Surface	Board Surface is broken, scratched or lack of some screw holes.	Feel free to contact us and we will get back to you within 24 hours.
	The screw holes on the wooden board and other wooden boards are not aligned.	1.Please tighten the screws on the board by 70 % , do not tighten completely. 2. Adjust the wooden board and board.Until the holes are arranged neatly, then tighten all screws
	Desktop misalignment and unevenness	1.Please tighten the screws connecting the table board to the elevator by 70%, do not tighten them completely. 2.Adjust to a flat and aligned desktop, then tighten the screws. 3.If your problem still can't be solved, please feel free to contact us.
Metal accessories	Metal accessories are damaged, rusted, bent, and broken.	Feel free to contact us and we will get back to you within 24 hours.
	The table is unstable after being assembled.	1.Check if the screws are tightened. 2.Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3.If your problem still can't be solved, please feel free to contact us.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.