




SY-01

80045 Product Installation Instructions







1x1




2x2




3x1




4x1



5x1



6x2




7x4




1


Accessories list

A		Non-slip pads (36x36x2mm)	4pcs
B		Rebound device & Screw (3x16mm)	4pcs +1pcs 1pcs
		Iron sheet & Hinge	2pcs 1pcs
C		Corner Bracket,Screw (4x8mm)	14pcs +2pcs
D		LED Strip Controlle	1pcs
E		AC/DC Adapter(12V=2.0A)	1pcs

Double-head screwdriver, use as required




1pcs




2

Product structure decomposition




Step 1

A



x4



4

Step 2

C






x4




x8



x4



Install this hole




Step 3

Ⓒ



x2



Step 4

(C)






x8




x16



x8



Install this hole




Step 5

Ⓒ



x4



Step 6



(B)



x1








x4



9




Step 7




Install this hole



Step 8



Install this hole





Step 9


Ⓒ



x6



Step 10




Step 11

Ⓒ




x6




Step 12

Note: Install the part onto the gasket, then tighten the screws.



If you feel loose, please pinch the accessory before installation




Locking screw

Step 13


(B)




x1




Step 14



first




second




third

Locking screw




Step 15

Ⓓ  × 1



Step 16

Ⓔ  × 1





User's Guide

Thank you for purchasing this product.

To use this product, please connect it to a power source.

Please use if the product works normally after connecting to power.

Introduction

The box is an intelligent controller.

It has five buttons for turning the light on/off, adjusting speed and light luminance changing light colors, and syncing with music beats.

Operation



This button is used to switch the dynamic color of the light.

Single Click: Switch dynamic lighting mode



This button is used to adjust speed and brightness.

In dynamic mode, click to adjust speed; in static mode, click to adjust brightness



This button is for turning the light on/off.

Single Click: Turn the light on/off.



This button is used to switch the static color of the light.

Single Click: Switch between 7 static RGB colors.



This button switches to music-synced lighting mode.

Single Click: Switch between 6 music-sync lighting modes



Dynamic Mode Button

Speed And Brightness Adjustment Button

Turn ON/OFF Button

Static Mode Button

Music Beats Button

⚠ ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If you have any questions when installing, please feel free to contact us. Thank you.