




INSTALLATION

Product Manual




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer—could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !





It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 109



M6 x 35 mm

B x 109



Ø15 x 9.5 mm

C x 13




M5 x 40 mm

D x 82




M3 x 12 mm

E x 3



F x 4



G x 8




M3 x 14 mm

H x 4



J x 4




96 mm

K x 8




M4 x 16 mm

L x 6




M x 12



P x 2



Q x 2



R x 4



M4 x 6 mm


S x 20



T x 20



M3.5 x 14 mm




⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*




1


A x 8
M6 x 35 mm

D x 4
M3 x 12 mm



E x 1
CL
CR
L = 300 mm




Fasten screw A to plate No.3.
Secure slide E-CR, E-CL to **same** plate No.3 with screw D.





Please note the screws holes positions of the two slides are different.




Flip to back




2




A x 4  M6 x 35 mm	D x 2  M3 x 12 mm	E x 1  CL L = 300 mm	
--	--	---	---





Fasten the screw A to plate No.1.
Fix the slide E-CL to plate No.1
with screw D.





3






Fasten the door suction seat F-1 to plate No.12 with screw G.






4




Connect plate No.1 with plate No.12 and No.10, and then add the lock B and tighten it.






5




Connect plate No.3 to plate No.12
and No.10, then add lock B and tighten it.





6




Fasten screw A to plate No.4.
Secure slide E-CR, E-CL to plate
No.4 with screw D.





**Please note the
screws holes
positions of the two
slides are different.**





Flip to back




7




A x 4  M6 x 35 mm	D x 2  M3 x 12 mm	E x 1  CR L = 300 mm	
--	--	---	---




Fasten screw A to plate No.2.
Secure slide E-CR to plate 2 with screw D.





8





Connect plate No.2 with plate No.12 and No.10, and then add the latch B and tighten it.



9




Connect plate No.4 with plate No.12 and 10, then add lock B and tighten it.



10





Fasten the door suction seat F-1 to plate No.13 with screw G.






11




Connect plate No.13 and No.11 with plate No.3, then add lock B and tighten.






12




Connect the two assemblies together,
and then add lock B to tighten.






13




Fasten screw A to plate No.7.






14




Fasten screw A to plate No.5 and 6.






15




Connect plate No.5 and No.6 to plate No.8, and then add lock B to tighten it.



16







Connect plate No.7 with plate No.5 and No.6, and then add the lock B and tighten it.




17

A x 20
M6 x 35 mm






Fasten screw A to plate No.9.



Flip to back






18





Connect plate No.9 to the assembly,
then add the lock B and tighten it.




19






Connect the two assemblies together,
and then add lock B to tighten.





Connect plate No.15 with plank No.31,
and then slide plate No.14, No.15
along available grooves.






21




Fasten screw A to plate No.16.
Secure the fitting (Q) to panel No. 16
using screw (D).






22





Connect the plate No.16 to the assembly,
then add the lock B and tighten it.




23




Fasten screw A to plate No.24.
Secure knob H with screw R.





24





Connect plate No.17 and
No.18 to plate No.23 with
screw C.






25




Slide plate No.25 into the chute, connect plate No.24 with plate No.17 and No.18, and then add lock B to tighten it.






26





Fasten slide E-DL, E-DR to plate No.17 and No.18 with screw D.




27




Fasten screw A to plate No.19
Secure knob H with screw R.








28





Connect plate No.17 and No.18 to plate No.20 with screw C.



29



Slide plate No. 25 along the groove, connect plate No. 24 with plates No. 17, No.18 and No.22, and then add lock B to tighten it. Connect plate No.20 to plate No.22 with screw C.




30

D x 4




M3 x 12 mm



E x 1



L = 300 mm





Fasten slide E-DL, E-DR to plate No.17 and No.18 with screw D.







31




Place the drawers into the cabinet




32



33



Connect plate No.28 to plate No.26, then add lock B and tighten it.






34


B x 12

 Ø 15 x 9.5 mm




L x 6


Connect the iron pipe L and plate No.27 to the assembly, and then add the lock B to tighten it.



35



Fasten screw A to plate No.29.



36

D x 8




M3 x 12 mm

F x 1

F-2



J x 1





96 mm

K x 2









M4 x 16 mm

M x 3



Fasten hinge M and door suction piece F-2 to plate No.29 with screw D.
Fasten the handle J with screw K.



37

D x 8




M3 x 12 mm

F x 1

F-2



J x 1






96 mm

K x 2





M4 x 16 mm

M x 3





Fasten the hinge M and the door suction plate F-2 to the plate No.29 with screw D. Secure handle J with screw K.



38





Connect plate No.29 to the assembly,
and then add the lock B to tighten it.



39



Attach plate No.29 to the assembly,
then add lock B and tighten.



40

D x 8




M3 x 12 mm

F x 1

F-2



J x 1





96 mm

K x 2









M4 x 16 mm

M x 3



Attach hinge M and door suction piece F-2 to plate No.30 with screw D.
Fasten handle J with screw K.



41

D x 8




M3 x 12 mm

F x 1

F-2



J x 1






96 mm

K x 2



M4 x 16 mm

M x 3




Fasten the hinge M and the door suction plate F-2 to the plate No.30 with screw D.
Secure handle J with screw K.

42


D x 12



M3 x 12 mm




Secure the hinge M to the cabinet with screw D.




43

D x 12
M3 x 12 mm





Secure the hinge M to the cabinet body with screws D.




44





Insert the back plate buckle S into the slots and fix with screw T.



45



Install the anti-tipping device.



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.