





CARTON CONTENT

WF319842:














B x 1

TABLE PART LIST FOR ONE			TABLE HARDWARE LIST FOR ONE				
NO	DESCRIPTION	SKETCH	QTY	NO	DESCRIPTION	SKETCH	QTY
A	CENTER SUPPORT		1 PC	1	WOOD DOWEL M8 x 30 MM		6 PCS
В	LEG RAIL	e e	2 PCS	2	JCBC SCREW M6 x 50 MM		22 PCS
C	TABLE LEG		4 PCS	3	SPRING WASHER M6	\bigcirc	22 PCS
D	LEG DOWN	C:	2 PCS	4	FLAT WASHER M6 x 13 MM	\bigcirc	22 PCS
E	TABLE TOP		1 PC	5	WOOD BUTTON 14.5 MM	\bigcirc	6 PCS
				6	ALLEN KEY M4		1 PC
						NOT INCLUDED	1












- DON NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR SET IS FULLY SET-UP.

CARTON CONTENT

WF319845:









	DINING PART	LIST FOR ONE	
NO	DESCRIPTION	SKETCH	QTY
A	CHAIR BACK		1 PC
В	WOODEN SEAT WITH APRON		1 PC
С	FRONT LEG		2 PCS


	DINING HARDWARE LIST FOR ONE				
NO	DESCRIPTION	SKETCH	QTY		
1	JCBC SCREW M6 x 35 MM	(()()	1 PC		
2	JCBC SCREW M6 x 50 MM		4 PCS		
3	JCBC SCREW M6 x 70 MM		4 PCS		
4	SPRING WASHER M6	0	9 PCS		
5	FLAT WASHER M6 x 13 MM	\odot	9 PCS		
6	ALLEN KEY M4		1 PC		
N	NOT INCLUDED				




CARTON CONTENT

WF319845:









G x 1

BENCH PART LIST FOR ONE				
NO	DESCRIPTION	SKETCH	QTY	
D	LEG RAIL	Coo	2 PCS	
Е	CENTER SUPPORT		1 PC	
F	BENCH LEG		4 PCS	
G	BENCH SEAT		1 PC	

BENCH HARDWARE LIST FOR ONE				
NO	DESCRIPTION	SKETCH	QTY	
7	WOOD DOWEL M8 x 30 MM	0	6 PCS	
8	JCBC SCREW M6 x 35 MM		10 PCS	
9	JCBC SCREW M6 x 50 MM		4 PCS	
10	SPRING WASHER M6	(0)	14 PCS	
11	FLAT WASHER M6 x 13 MM	\bigcirc	14 PCS	
12	WOOD BUTTON 14.5 MM	0	6 PCS	
13	ALLEN KEY M4		1 PC	
NC	OT INCLUDED			

