

Chair

USE AND CARE GUIDE



Chair

Questions, problems, missing parts?

Before returning to the store, please contact our Customer Service

THANK YOU

We appreciate the trust and confidence you have placed in our store by purchasing this sling chair. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Table of Contents

Table of Contents	01
Important Safety Information	02
- Product Caution	02
- Safety Warnings	02
Warranty	03
Pre-Installation	03
- Planning Installation	04
- Hardware Included	05
Installation	06
Care and Cleaning	14

Important Safety Information

Product Caution

Before You Start

- Important: Retain these instructions for future reference.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent it from scratching.
- Check the pack and make sure you have all the parts listed.
- Do not use power tools to construct this product.
- Ensure that this product is fully assembled as illustrated before use.

Safety Warnings

- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- Do not move the furniture set while it is occupied. Failure to obey this caution could result injury.
- When placing in the desired location, ensure that all legs are resting on the same surface.
- To prevent damage, place all parts on a soft surface during assembly.
- This set was made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; However, the manufacturer recommends storing and/or covering this product when any formidable/severe weather is approaching.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- This product should only be used on firm, level ground.
- Keep small parts out of reach of children.
- Do not tighten screws until fully assembled.
- Do not overtighten screws or bolts.
- Do not sit on the arms of the chair.

Warranty

1 YEAR FRAME, WEAVE AND FABRIC WARRANTY

What Is Covered

We warrant the frame, weave and fabric to be free of manufacturing defects to the original purchaser for 1 year. For glass table top we warrant 30 days from the date of purchase.

What Is Not Covered

This warranty does not cover commercial use, hardware, acts of nature, reuse, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Pre-Installation





Planning Installation

To prevent damage, place all parts on a soft surface during assembly. Remove all protective caps before beginning assembly.



CHAIR
300 LBS
CAPACITY

Hardware Included



Hardware Included



(4PCS)
M6*60

F



(4PCS)
M6*50

G



$\Phi 12$
(12PCS)

H



(1PCS)

I



(4PCS)

J



(8PCS)

K



(4PCS)

L



(1PCS)

M



(1PCS)

N



$\Phi 16$
(1PCS)


O





(1PCS)

P


Part	Description	Quantity
A	Armrest	2
B	Front/back connecting tube	2
C	Seat	1
D	Support tube	1
F	Bolt (M6*60)	4
G	Bolt (M6*50)	4
H	Washer	12
I	Wrench	1
J	Nut	4
K	Bolt cap	8
L	Nut cap	4
M	Back width adjustment nut	1
N	Back width adjustment bolt	1
O	Washer	1
P	Allen Key	1



STEP 1



STEP 2





F




H



P





!!! Turn it twice






! Caution: Don't tighten these two bolts before step 6, only turn them twice, otherwise it will cause the other side of the sling tube can't be installed.

STEP 3




STEP 4


 $\Phi 16$
 (1PCS)








Before





After

STEP 5



STEP 6



!!! Caution: Please fully tighten all bolts before step 6. Loosen part N with the wrench I to make the fabric straighter. In the process of loosening, if part M will turn with part N, please hold part M with your fingers to keep it still.

STEP 7





(8PCS)

K



(4PCS)

L



Care and Cleaning

- To clean wipe with a sponge and warm soapy water then wipe with a dry, clean cloth.
- Do not use solvent based cleaners or detergents as they can bleach or damage the product.
- Clean the fabric using warm soapy water only. The product must be thoroughly dried afterwards to prevent mildew or mould stains from forming. Most stains can be removed with a mild soap.
- Never use a pressure hose or washer to clean the product.
- Never use scourers, abrasives or chemical cleaners.
- Wipe clean with a soft dry cloth.
- Store the product in a cool dry place. Before storage ensure that it is clean and dry.
- We recommend the use of furniture covers to protect your product when not in use. During bad weather and winter months the product should be stored in a cool dry place.
- To clean metal frame, use a soft cloth moistened in lukewarm soap and water. Then buff with a dry clean cloth.