























PARTS LIST

1  Φ8*50mm 30pcs	2  Φ8*70mm 9pcs	3  1pc
4  4pcs	A  1pc	B  9.6" 4pcs
C  11.8" 7pcs	D  1pc	E  1pc
F  1pc	G  11.8" 8pcs	H  11.8" 2pcs
I  1pc	J  21.6" 2pcs	K  1pc
L  9.6" 1pc	M  1pc	N  1pc
O  1pc	P  1pc	R  1pc

ASSEMBLE STEPS

HOUSE



Anti-tipping Device




Mark the screw holes with a pen.




Drill holes into the wall




Use a hammer to insert expansion nails



Attach the mount to the wall with long screws



Attach the mount to furniture with short screws



Pass the cable through both mount holes and fasten the connector

