



Installation Guide

Tools Required



Light Source



Option 1 (socket up): Fixture Height Adjustable 32" to 129.5"

Warnings and Cautions

Turn off the electricity at the circuit breaker before installation. Consult a licensed electrician if in doubt about installation.


Turn off power to the fixture and allow the bulbs to cool before replacing.

Package Contents

Preparation: Identify and inspect all parts before beginning the installation.

Missing or damaged parts? Contact your original place of purchase.

PARTS BAG




A Crossbar Assembly x 1




B Outlet Box Screw x 2




C Wire Connector x 3



D Quick Link x 2



E Fixture Chain x 1



F Ceiling Canopy x 1



G Fixture Loop x 1



H Rod x 2




I Center Column x 1



J Socket Collar x 9




K Shade x 9



L Fixture Body x 1


Table of Contents

Fixture Loop, Rods & Center Column



STEP 1

Crossbar Assembly




STEP 2

Fixture Chain




STEP 3

Wiring




STEP 4

Ceiling Canopy




STEP 5

Shade & Bulb



STEP 6


STEP 1





STEP 2

- 1 ----- 2 ----- 3

Step 1
Install crossbar assembly




Step 2 - 3
Test fitting ceiling canopy to nipple



STEP 3


1

Step 1
Adjust fixture chain length




2

Step 2 - 3
Install Fixture Chain




3




STEP 4

1


Step 1
Feed the fixture wires
through the loop



2



STEP 5



STEP 6

