


# Assembly Instruction Sheet for Model HL845028

## Package Contents

Part	Description	Quantity
A	Fixture Body	1 pc.
B	Ceiling Canopy	1 pc.
C	Metal Board	1 pc.
D	Fan Blade	1 pc.
E	Lamp Shade	1 pc.
F	LED Circuit Board	1 pc.
G	Acrylic Diffuser	1 pc.
H	Mounting Bracket	1 pc.
I	Remote Control	1 pc.



### STEP 1

Mark the drilling position on ceiling with the help of the Mounting Bracket(A).  
Drill holes on the marks and stick the expansion anchors into the holes.  
Fix the Mounting Bracket(A) to the expansion anchors with self-tapping screws.

### STEP 2

Twist fix the threaded tubes to the petals of the Fixture Body(B).  
Pull out the excessive wires of the petals to the canopy,  
and fix the petals to the canopy with the washers and nuts.

### STEP 3

Align the holes of the Wreath(C) to the holes of the canopy,  
and fix the Wreath(C) to the canopy with the screw bolts and nuts.

### STEP 4

Place the Fan Blades(D) on the canopy, and fix with the Lock Cap(E).

### STEP 5

Test the fixture if it can work.

### STEP 6

Hold the fixture close to the ceiling.  
Connect live line to the Black or Red wire from the canopy of Fixture Body(B).  
Connect neutral line to the White or Blue wire from the canopy of Fixture Body(B).  
If two wires are identical, the wires do not distinguish between a live line and a neutral line.

### STEP 7

Attach the canopy of Fixture Body(B) to the Mounting Bracket(A).

Your fixture is now assembled and ready to use.