

DINING TABLE

ASSEMBLY INSTRUCTION



ASSEMBLY INSTRUCTIONS

Assembly Instructions

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

Warning!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial




ASSEMBLY TIME PER UNIT:

20 MINUTES

PARTS IDENTIFICATION

A.



1PC

B.



LEG


4PCS

ASSEMBLY INSTRUCTION

Z	HARDWARE IDENTIFICATION		
1	ALLEN KEY-BIG M5mm		1PC
2	ALLEN BOLT-BIG Ø5/16"*2"		8 PCS
3	SPRING WASHER-BIG Ø5/16"		8 PCS
4	FLAT WASHER-BIG Ø5/16"*19mm		8 PCS

ASSEMBLY INSTRUCTION

STEP 1



STEP 2

