


Assembly Instruction

Furinno TV Stand

MODEL : 20230



Customer Support

NEED HELP? For replacement requests or product inquiries, please contact our Customer Service Team by emailing us at support@furinno.com. Thank you for selecting Furinno!


www.furinno.com



HARDWARE & PARTS LIST

NO	HARDWARE LIST	QTY
1	MINIFIX  (1a)  (1b)	8Sets
2	CHIPBOARD SCREW 	8pcs
3	DOOR SPRING 	4pcs
4	MAGNET 	2pcs
5	SCREW 	2pcs
6	MINI LEG 	5pcs
7	SHELF SUPPORT 	4pcs
8	POWER PIN 	28pcs


NO	PARTS LIST	QTY
A	TOP PANEL	1pc
B	BOTTOM PANEL	1pc
C	LEFT SIDE PANEL	1pc
D	RIGHT SIDE PANEL	1pc
E	LEFT CENTER PANEL	1pc
F	RIGHT CENTER PANEL	1pc
G	LEFT DOOR PANEL	1pc
H	RIGHT DOOR PANEL	1pc
I	ADJUSTABLE SHELF	1pc
J	BACK PANEL	1pc




USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

STEP 9



Recommended Maximum Weight



*Unit in Pound(lbs.)


WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.


>DO NOT allow children to climb on unit.

> Put heavier items on lower shelves.

STEP 7



STEP 8




*repeat for left door.


ASSEMBLY INSTRUCTIONS

BEFORE YOU BEGIN, PLEASE READ ASSEMBLY INSTRUCTIONS CAREFULLY,
FOLLOW THEM STEP BY STEP.


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

