


ASSEMBLY INSTRUCTIONS

BATH VANITY-CABINET

SKU - N710P333972





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED



*Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!
* Please assemble on a clean soft surface to avoid damage.




+



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY










Before Installation

~~Important- Please read these instructions fully before starting assembly~~


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions






















		Diagram A Insert Cam Ball into hole as shown in diagram A.	
		Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the cam Lock to be misaligned and unable to interlock properly.	
		Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.	
			Connect the panels together.
			Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
			To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View




Identifying the Hardware-Identify the hardware using the illustrations below.

SKU - N710P333972

1		2		3	
	Side Panel (L) - 1pc		Side Panel (R) - 1pc		Mid Panel - 1pc
4		5		6	
	Bottom Panel - 1pc		Adjustable Shelf - 1pc		Top Rear Crossbar - 1pc
7		8		9	
	Bottom Rear Crossbar - 1pc		Middle Rear Crossbar - 1pc		Bottom Frame - 1pc
10		11		12	
	Leg - 4pcs		Top Front Crossbar - 1pc		Door Cabinet - 1pc
13		14		15	
	Drawer Face - 1pc		Side Drawer Panel (L) - 1pc		Side Drawer Panel (R) - 1pc
16		17		18	
	Rear Drawer Panel - 1pc		Bottom Panel - 3pcs		Drawer Face - 2pc
19		20		21	
	Side Drawer Panel (L) - 2pcs		Side Drawer Panel (R) - 2pcs		Rear Drawer Panel - 2pcs







SKU - N710P333972

22






Sink - 1pc





Hardware Lists N710P333972

A  Ø8x20mm	B  Ø6*32mm	C  Ø14.5*9.5mm
Wood dowel (23pcs)	Three in one bolts (22pcs)	Three in one locks (22pcs)
D  Damping hinge (2 sets)	E  M6x30mm	F  M6x45mm
Damping hinge (2 sets)	Hex-Head bolt (7pcs)	Hex-Head bolt (9pcs)
G  Washers (13pcs)	H  Pin shelf (3pcs)	I  Ø3x12mm
Washers (13pcs)	Pin shelf (3pcs)	Round head screw (3psc)
J  Handle (4pcs)	K  M4x15mm	L  45*12*1mm 45*17*14mm
Handle (4pcs)	Handle screw (4pcs)	Plastic Door Magnet (1 set)
M  Ø3x15mm	N  Ø10x10mm	O  M4x50mm
Flat head screw (4pcs)	Plastic Canopy (12pcs)	Round head screw (12psc)
P  Ø8xØ4*30mm	Q  Anti fall Hardware (2 sets)	R  K4mm
Round head screw (15psc)	Anti fall Hardware (2 sets)	Allen key (1pc)


STEP:1



B	
9pcs	
L	
1pc	
M	
2pcs	



STEP:2



A




1pc

C



2pcs

STEP:3



R



A



11pcs

C



1pc

E




6pcs

G



4pcs

STEP:4



A




6pcs

C



6pcs

STEP:5



F



8pcs

G




8pcs

R



STEP:6



A




4pcs

P



2pcs

STEP:7




P



10pcs

STEP:8




P




2pcs

STEP:9



D




2pcs

D



4pcs

L






1pc

M




2pcs


STEP:10



STEP:11

J


1pc

K


1pc

D


8pcs




Use the screws to adjust up or down







Use the screws to adjust in or out




Use the screws to adjust left or right







STEP:12




B	J	K
		
4pcs	1pc	1pc
C	N	O
		
4pcs	4pcs	4pcs


STEP:13





B	J	K
		
8pcs	2pcs	2pcs
C	N	O
		
8pcs	8pcs	8pcs




STEP:14





STEP:15




STEP:16



*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

