



PRODUCT DESCRIPTION

1.This machine can print picture onto cotton,flax,chemical fiber and other fabrics through heat transfer.It can carry out screen print ,flue,foam and other heat treatment technology,,and it can also color code ,portrait,landscape pattern onto the porcelain,metal plate. It can produce more pressure depends on its special design which is suitable for continuous production of normal heat transfer American heat transfer T-shirt and other products,econo-mical and practical.

Voltage:110/220V	Power: 1150-2800W
Temperature Range 0-220℃	Time control:0-999Sec
Working Area :38*38CM/40*60CM	
Packing Size:73*45.5*46CM/81*72*46CM	

FEATURE

Microcomputer intelligent thermostat/time integration controller,high accuracy,with temperature automatic tracking function (temperature accuracy to $\pm 0.5^{\circ}\text{C}$)

Heat wire and the heating plate integral casting, safety, durability,evenly hrat distribution,not variant

The heating plate adopts special ultra precision line tube technology,which can effectively ensure the balanced and stable temperature

Electronic time control, process completion warning signals spiral pressure design,can be easily setup work pressure

Platform installs high temperature resistant foaming silicon sheet,heat resistance to 350°C not deformation

MAINTENANCE

1.Pressure:if not enough or too much, can adjust pressure screw rod, Clockwise can increase pressure,counter clockwise can reduce pressure.

2.Time :buzzer do not ring or soynd continuously when time is up need you check micro switch contact suitable or not which is on chassis rear or need to adjust to tie suitable position

3.Temperature:preheat about 15min,Heating indicator light off when up to the set temperature then start to heat transfer please check line if hot plate do not fever when power on for minutes

4.When handle press down, release hand handle rise back automatically please adjust not down when heat transfer is over can adjust screw up when feel hard to handle

INSTRUCTIONS

Control panel introduction:

1. Start: Turn on the switch knob, press and hold the switch key, the machine will turn on;
2. Temperature Setting: Press the Temp line,the Temp will flash, then press “+”and “-” key to adjust the Temp;
3. Time Setting: Press the Time line,the time will flash, then press “+”and “-” key to adjust the Time
4. When Press down the handle, timer will work automatically.

TRANSFER TEMPERATURE EXPLANATION

For light transfer paper:

Temperature:180--185degrees time :20-25Sec

For dark transfer paper:

Temperature:160-165degrees time:12-15Sec

For sublimation paper:

Temperature:180-190degresss time:60-90Sec

For heat transfer:

Temperature:160-170degrees time:10-15Sec

ATTENTION:

1. When you open the box, please be attention to bounce !!!!
2. When you take out the machine ,please use both hands holding the downside aluminum plate !!!!