

Assembly Instructions

Caution : You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



- Stains may be removed with mild soap solution and damp cloth.




- Keep away from sources of ignition.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in the Seat Panel for hardware packs.

DINING CHAIR





CAUTION: This Chair is NOT a TOY

Keep your child / children at bay during the assembly process.

For turning the Chair and to prevent damage to the product, 02 adults may be needed to execute this action

Parts List


Label	Picture	Description	Qty
A		Backrest Panel	1
B		Left Arm	1
C		Right Arm	1

D		Seat Panel	1
E		Seat Cushion	1

Hardware

Label	Picture	Description	Qty
①		Bolt (M6x40mm) +Extra 1 pc	9
②		Bolt (M6x45mm) +Extra 1 pc	4
③		Flat washer (17x7x1mm) +Extra 1 pc	13
④		Allen wrench	1

Assembly Preparation





- Read instructions, cover to cover



- Have 2 adults on hand for assembly



- Do not assemble on the flooring or carpet




- Assemble on a clean, non-marring surface (packing foam)



- Save all packaging until finished.


Assembly Steps

Overview




This Chair has multiple parts and may require up to 15 minutes to assemble. To give you an overview of the Dining chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise the parts and steps before assembly.

Step 1:




Unpack and place all the parts on a clean, non-marring surface.

Step 2:




Using bolts ②, flat washers ③, and the allen wrench ④ to connect the left/ right panel B C to the backrest A. **Do not fully tighten the bolts.**

Step 3:




With your adult partner's help, turn over the cluster in Step 2. Put the seat panel D to the cluster.

Step 4:




Using bolts ①, flat washers ③, and the allen key ④ to fix the frame in Step 3.
Do not fully tighten the bolts.

Step 5:




At the intersections, using bolts ①, flat washers ③, and the allen wrench ④ to enhance the dining chair strength. **Do fully tighten all the bolts in this chair.**

Step 6:



Put the seat cushion E on the Dining chair.

Step 7:



Warning: If your Dining chair is not stable, it could damage the product.
Your Dining chair is ready to use.
This chair can only be used on a flat, level surface.