ASSEMBLY INSTRUCTION

Ax1



Bx1



Cx4

Dx1

Ex4 M8X30



Fx12 M6X18

Gx4

①



②



③