

TOOLS REQUIRED



Philips Screwdriver



2 - People Recommended





The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



				i
L				
L				
L				
L				
_	_	_	_	ł

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Save the instructions and store any supplied tools for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CAM LOCK FASTENER ASSEMBLY INSTRUCTIONS


Note :

Every cam lock bolt must have a cam lock connector in order to fasten the parts together.










Screw the cam bolt into panel.




Align the cam lock with its side opening (or arrow) pointing to cam bolt.


cam bolt

cam lock

ock



Insert the cam bolt into the bolt hole of joint panel.




Turn the cam lock clockwise gently until it will not turn any more.

Wine Cabinet




• Please keep instructions for future reference.

 Check the quantity and irregularity of parts and hardware before you start.





PARTS





IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC IPC
$\blacksquare \square \square$


Hardware (1) x 2PCS Hardware (3) x 2PCS A5 Accessory (A5) x 1PC OPTIONAL 1 Apply a dab of glue into dowel holes of panels before 3 inserting dowels (#3). 3 2 Part 🕅 x1PC Part 🚺 x1PC Part () x1PC Part P x1PC Part 🔘 x1PC Hardware ② x 2PCS Hardware ④ x 4PCS Accessory (A1) x 1PC Accessory (A2) x 1PC Ø P 0 $(\Lambda$ Q. 1 2 0 4 Ŵ Please refer to Page 5 for detailed instructions on how to fasten cam locks (#2) to cam bolts (#1). 20 2 (A1 A20






















16

Part () x1PC Hardware () x 8PCS Accessory (A1) x 1PC Accessory (A2) x 1PC





19

ASSEMBLY COMPLETED




Please ensure the furniture rests on an eve and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.




Wall Mounting and Fixing




EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. liability for product damage or failure due to using the incorrect anchors will fall on the installer.



CHECK BEFORE PROCEEDING

Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.



) MAINTENANCE



We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.