

Ice Crusher Machine



Owner's Manual

IMPORTANT SAFETY PRECAUTIONS



To minimize the risk of injury, read and heed these important safety precautions when operating this machine. Following these precautions, as well as general safety rules as you would for any work area will help to prolong the life of your machine.

- . **DO** keep your work area clean, well lit and free of any obstructions.
- . **DO** wear proper eye protection and hand protection such as safety glasses and gloves while machine is in use, servicing or maintaining your machine.
- . **DO** ensure that your machine is properly grounded to avoid potential electric shock.
- . **DO** unplug your machine before any service or maintenance to prevent potential electric shock.
- . **DO** be sure to route your drain tube into a bucket or drainage grate. Avoid the buildup of water puddles and potential slip and fall injuries.
- . **DO** read and refer to these precautions, warnings and instructions before you operate this machinery. Please refer to this manual often.

- . **DO NOT** make any alternations to your machine. Altering your machine will void your warranty and could result in serious injury.
- . **DO NOT** immerse any part of your machine in water. Immersion may result in damage to the machine.
- . **DO NOT** allow untrained personnel, the public, and especially children to operate or have direct, physical contact with the machine.
- . **NEVER** put objects (knives, utensils, picks) near or into the shaver assembly while machine is in use. Keep body parts well away when machine is in operation. **FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.**

Great Northern Popcorn Company will not be responsible for injury that occurs as a result of failure to follow these precautions.

DO NOT operate when under the influence of drugs or alcohol.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. To protect against risk of electrical shock do not put the unit in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. This machine must not be operated by anyone under the age of 18.
5. Unit must be operated in a flat, level position.
6. This machine must be connected to a grounded outlet.
7. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
8. Avoid contacting moving parts. Never place fingers or other utensils into feed or discharge areas.
9. **Do not** operate any appliance with a damaged cord, plug, after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the vendor for examination, repair for electrical or mechanical adjustment.
10. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
11. Household use only; **Do Not** Use Outdoors.
12. **Do not** let cord hang over edge of table or counter or touch hot surfaces..
13. Visually inspect the ice chopper for presence of foreign objects before using and while the machine is unplugged and the power switch is off.
14. **Do not** place on or near a hot gas or electric burner or in a heated oven.
15. **Do not** clean unit with steel wool.
16. **Do not** spray controls or outside of unit with liquids or cleaning agents.
17. To disconnect, turn the power switch to OFF, then remove plug from wall outlet.
18. **Do not** use appliance for other than intended use.

Purpose

This machine is intended to be used for crushing ice in a household setting.

Before using this machine, it must be cleaned and dried thoroughly. Clean all surfaces before use with soap and water.

The ice crushing machine is intended to crush ice cubes for use in beverages and snow cone treats. Ice cubes should be a maximum of 2 inches in diameter. Larger pieces should be broken up before entering the machine.

INSTALLATION AND OPERATION INSTRUCTIONS

1. Place the machine in a place where it cannot be tipped or pushed off counter.
2. Keep the area in front of the machine clear to allow unobstructed access while in operation.
3. Keep machine and power cord away from open flames, electric burners or excessive heat.
4. Use only grounded electrical outlets rated for 120V.
5. Do not use an extension cord with this machine.
6. Do not spray controls or outside of machine with liquids or cleaning agents.

OPERATION

1. Position your Ice Crusher Machine in a workspace large enough and clear from obstructions while operating.
2. Open the safety-shield, wipe the shaving plate with a dry cloth.
3. Place an ice block on the shaving plate. Do not overfill.
4. Adjust the ice claw to secure the ice block by rotating the handle until the ice claw teeth penetrate the ice block.

Warning: The teeth of the ice claw are sharp, do not touch.

5. Close the safety shield. Place a cup or bowl under the ice chute. Turn the switch to on. Replace the block when there is ¼" left. Do not let the ice claw touch the shaving plate while operating. To stop shaving the ice turn the switch to off.
6. Your crushed ice will deposit into cup or bowl below and is ready to use and enjoy.

WARNING



Sharp blades, do not place hands in or near the ice chute while motor is running.



Keep water and other liquids from entering the inside of mechanical and electrical components of the Polar Blast. Liquid inside the mechanical and electrical components could cause an electrical shock.

CARE FOR YOUR ICE CRUSHER

Please clean your unit after each use to prolong service life and appearance.

NOTE: Do not clean machine with steel wool.

1. Allow machine to cool before cleaning.
2. Unplug your Ice Crusher Machine.
3. Remove cord from socket and never immerse plug or controls in water or any other liquid.
4. Do not use solvents or chemicals to clean machine.
5. Use a damp cloth to wipe down the shaving plate, ice claw, all interior and exterior surfaces.
6. Dry thoroughly after cleaning.

TECHNICAL PARAMETER

Voltage:110V	Input:250W
Frequency:60Hz	Own Weight:37.5lbs
Device size:15.7''L x 12.2''W x 32.7''H	Speed:1400r/min
Packing size:19.3''L x 14.4''W x 29.3''H	Quantity of smash ice:210lbs/hr

CUSTOMER SERVICE

Contact us through our website: www.TeamCustomerService.com

If you have any question about assembly, use or possible missing part, please contact us and we will be glad to assist you.