
















CHEF KITCHEN STATION
JET 1905 - JET 3185
ASSEMBLY INSTRUCTION





STEP 1





STEP 2



STEP 3



STEP 4



THE WASTE BAG HOLDER AND THE CONTAINER
CAN BE USED ALTERNATELY OR TOGETHER