



# 21x29cm

## 12568



### # 12568 Gyroscope Wind Spinner 86" ASSEMBLY INSTRUCTIONS

#### PARTS LIST:



Note: Before staking into the ground, make sure the ground is soft.  
If the ground is not soft, moisten the ground with water.

WARNING: Do not leave out in high winds as it may damage the product.