



Assembly Instruction

PART LIST


Ax1




Bx1



Cx1



Dx4




Ex16




Fx1




Step 1




Step 2



Step 3



Step 4



Step 5

