

Assembly Instructions









CD0516GF21D

Your recliner comes packaged in two boxes. Carefully remove all of components from the packaging and set aside for assembly.

CAUTION


DO NOT use any sharp objects to open plastic wrapped components as this may result damage to product or components .

Package Contents


A 	B 	C 	D 
Chair seat	Backrest	Left armrest	Right armrest
E 	F 	G 	H 
Massage Remote	Power Source	Power Cord	2*Supporting Feet

STEP 1

Find a small bag in the accessories box. Take out Supporting Feet(H) from the small bag. Assemble the two Supporting Feet as shown on the bottom of mechanism to avoid toppling and falling.




STEP 2



Insert two armrests to the chair base, make sure the slots on the armrests fully assembled to the bottom part.

STEP 3

Insert chair back to the chair base, make sure the slots on the back fully assembled to the bottom part.




Note

- No.1 and No.2 wire connect with the backrest and chair seat.
- No.3 wire connects with backrest and power cord(G).
- No.4 wire connects with backrest and massage remote(E).
- No.5 wire connect the motor and the wire from rightside armrest, which use to connect the control panel.
- No.6 wire connect the motor and power source (F).

NOTE

- 1: Two same color wires connect.
- 2: Plug **Power Cord (G)** and **Power Source (F)** into outlet, then you can use all function.



Warnings

1. Please check if the components of the chair are all included and can be used normally as the 5th tip.
2. Assemble all components according to the instruction correctly before you connect the chair with the power.
3. Please DO NOT sit on the armrests and footrest to eliminate the risk of tipping over.
4. If the sofa is damaged or doesn't match the website product, please send clear pictures of the product and label of the carton to our service team, and we'll help you to solve the problem.
5. If the recliner doesn't work, you can try the following measures for self-checking firstly:
 - ① Check if all the cable are connected;
 - ② Check if the light of transformer is on.If the chair still doesn't work, please feed the information back to the customer service in time. We will help solve the problem for you as soon as possible.
6. If you have any questions with the product, please contact us by:

Email: kalmiliving@yeah.net (we will reply to you within 24 hours)

