


Bio Ethanol Tabletop Fire Pit



ASSEMBLY INSTRUCTION

Model No : FP24940- WX

Need help? We are here for you!

Email us: Haullisum@hotmail.com



WARNING

**FIRE AND EXPLOSION HAZARD.
SEVERE BURNS OR DEATH CAN OCCUR.
NEVER ADD FUEL TO A HOT DEVICE.**

WARNING


- 1、 Remember fire pit fuel is highly flammable and extremely dangerous if not handled according to instructions. Be sure to read this safety instruction prior to operate the fire pit.
- 2、 The decorative fire pit should be placed on a level ,stable and suitable surface,so that it will not tip over.
- 3、 Use 91% or higher isopropyl alcohol or more than 97% ethanol as fuel, Never fill the reservoir higher than 1 inch from the edge.
- 4、 Do not use gasoline or other flammable vapors and liquids in the fire pit.
- 5、 Keep a safe distance from the inflammable materials, The minimum distance to loose the textile ,such as curtains, should be 40inch and there should be 59inch free space above the burner opening.
- 6、 Flame follows fuel, spilled fuel should be cleaned with a dry paper towel or a rag before lighting.
- 7、 Use only an extended lighter or long match to ignite
- 8、 Never touch the glass shield while in use, Hot glass will cause burns and injuries, Never refill, move or touch the fire pit while burning or when it is still hot.
- 9、 Never leave children or pets unattended near the fire pit during use.
- 10、 If lit fuel spills, suffocate to extinguish or spray with a fire extinguisher. Cover to extinguish out, Do not attempt to blow out.
- 11、 Any cracked or broken glass shield must be replaced .Continuing use under this condition may cause injury.
- 12、 The fire pit should never be activated, handled, or filled by minors.
- 13、 Never leave a burning fire pit unattended.

- 14、 Do not burn longer than 1.5 hours at a time without letting the fire pit cool to the touch.
- 15、 Do not open fuel container next to open fire. Always confirm bottles are tightly sealed, keep out of reach of children.
- 16、 Fuel should be store in a dry, cool place at least 60 inch from fire pit.
- 17、 Do not leave unit fuel in burn chamber. Flame can be snuffed out but fuel must then be emptied.
- 18、 Discontinue use and contact customer service immediately if cracks appear or fuel or flame shows on the outside of the unit.


Maintenance and Cleaning

1. After the fire pit is cooling, wipe the residual alcohol on the stainless steel lining with dry paper towels or rags, and store the fire pit in a dry place.
2. Discontinue use and contact customer service immediately if cracks appear or fuel or flame shows on the outside of the unit.


PART LIST

Item	Picture	Description	Qty
①		Table Top Fire Pit	1
②		External Steel Cup	1
③		Inner Steel Cup And Wool Wick	1
④		Lid	1
⑤		Glass Tube	1
⑥		Roasting Forks	4


OPERATION GUIDE




Step 1, Insert the inner steel cup ③ to the External Steel Cup ② , and insert two cups to the opening located at the top of fire pit ①




Step 2, Pour the fuel(Bio Ethanol) into the steel cup carefully.



Step 3, Use a long match or lighter to ignite the tip of wick. Hold the flame for at least 5 seconds to ensure the fire is lit.



Step 4, Insert the glass tube ⑤ to fire pit ①.



Step 5, Place snuffer over the top of the glass tube to extinguish flame.