


TWO NOTE DOOR CHIME

READ AND SAVE THESE INSTRUCTIONS

WIRING

TURN OFF POWER AT BREAKER BOX BEFORE WIRING THIS CHIME.


ALL ELECTRICAL WORK MUST BE DONE IN ACCORDANCE WITH LOCAL AND/OR NATIONAL ELECTRICAL CODE AS APPLICABLE.



INSTALLATION

TURN OFF POWER AT BREAKER BOX BEFORE INSTALLING, WIRING, OR SERVICING THIS PRODUCT.


1. Bring wiring through access hole in chime mechanism.
2. Attach chime mechanism to wall with screws provided.
3. Connect wires to correct terminals as shown in wiring diagram.
4. Turn on power. Make sure push buttons operate door chime properly.
(Two notes for front door, one note for second door)
5. Must use hanging bracket installed in chime cover to mount this chime cover. Do not hang cover onto chime mechanism base due to its weight.
6. Mount the transformer to a rafter or junction box as shown in Fig A.




LIMITED WARRANTY

Door Chime Wiring


One Door Chime



Two Door Chimes



Three Door Chimes



Note: Some chime mechanisms have a terminal marked "O Bell". This is not to be used with a transformer.

LIMITED WARRANTY