


Assembly Instructions

ITEM#77593

PART LIST


												
WOOD TOP	SIDE FRAME	MIDDLE FRAME	WOOD BASE	SUPPORT RAIL	SHELF	BOLT	ALLEN KEY	WASHER	HEX NUT	WRENCH	SCREW	SCREW DRIVER
1PC	2PCS	1PC	1PC	2PCS	1PC	6PCS	1PC	6PCS	12PCS	1PC	2PCS	1PC

2) Step by Step Instructions

★PS: Best to use electric screw driver supplied by consumer.


STEP 1

Place the two side and one middle frames, wood top and wood base on a flat level surface. Using the washers and hex nuts assemble the wood base to the left side and middle frame sections first.




STEP 2

Attach shelf to the frame and fix another side frame. Note: Be sure to have the side frame facing in the same direction so that you are able to attach the support rail. Do not tighten connections firmly yet.




STEP 3

Using the allen key and bolts assemble the top to the side and middle frames, and attach shelf using the wood screws and your screwdriver. Do not fully tighten yet.




STEP 4

Using the wrench and hex nuts attach the one side of X shaped support rail.



STEP 5

Repeat the same step to attached another X shaped support rail.



COMPLETION

Firmly tighten all screws and hex nuts from each of the prior steps.

