


GLOBAL PROCUREMENT AND MARKETING LIMITED

Batley Small Radiator Cover

Assembly Instructions – Please keep for future reference

RADBATXSW



Dimensions	No. people	Assembly Time	SKU #
Width: 78 cm		30 mins (approx.)	RADBATXSW
Depth: 19 cm			
Height: 96 cm			

thank you

For purchasing this
GPM Limited
product

Important

- PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY
- PLEASE DO NOT THROW THE PACKAGING AWAY UNTIL YOU ARE SATISFIED WITH PURCHASE, GOODS NEED TO BE RETURNED IN ORIGINAL PACKAGING.

If you need help or have damaged or missing parts, please email aftersales@gpmfurniture.co.uk

Safety and Care Advice

Important

- PLEASE READ THESE INSTRUCTIONS FULLY BEFORE STARTING ASSEMBLY
- PLEASE DO NOT THROW THE PACKAGING AWAY UNTIL YOU ARE SATISFIED WITH PURCHASE, GOODS NEED TO BE RETURNED IN ORIGINAL PACKAGING.

- Check you have all the components and tools listed on pages 4 and 5.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to lay out the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft, level surface to avoid damaging the unit or your floor.
- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.




Care and Maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

If kept outside please ensure in the winter months that the product is correctly covered or put away into a dry environment to prevent corrosion, weathering or damage.


If your product is not designed to be outside, we recommend that it is always kept indoors in a dry environment.

SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT



QUICKFIT


Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



If you are unhappy with the product and wish to return it, please follow the retailer's returns procedure.

Exploded View

If you have damaged or missing components,
email: aftersales@gpmfurniture.co.uk



Components - Panels

Please check that you have all the components listed below before constructing your item.

Part No	Description	Qty	Size (mm)	Thickness (mm)
1	TOP PANEL	1	780x190	12
2	LEFT PANEL	1	950x180	12
3	RIGHT PANEL	1	950x180	12
4	BACK PANEL	1	735x138	3
5	TOP BOTTOM PANEL	1	726x180	12
6	FRONT PANEL	2	726x375	12
7	DRAWER FRONT PANEL	1	722x124	12
8	DRAWER SIDE PANEL	1	152x115	12
9	DRAWER SIDE PANEL	1	152x115	12
10	DRAWER BACK PANEL	1	698x115	12
11	DRAWER BOTTOM PANEL	1	705x146	3

Important – Please read these instructions fully before starting assembly










If you need help or have damaged or missing parts, please email aftersales@gpmfurniture.co.uk

Components - Fixings


If you have damaged or missing components,
email: aftersales@gpmfurniture.co.uk

Please check that you have all the components listed below before constructing your item.


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

(A)	CAM lock dowel x20 	(B)	CAM lock x20 	(C)	 x2	(D)	Screw x4 M3x12mm 
(E)	Screw x4 	(F)	 x1	(G)	Wood block x2 	(H)	Screw x4 
(I)	Wall anchor x4 						

Tools Required



Ruler – Use this to measure your screws (mm)



Important – Please read these instructions fully before starting assembly



If you need help or have damaged or missing parts, please email aftersales@gpmfurniture.co.uk

Assembly Instructions


If you have damaged or missing components,
email: aftersales@gpmfurniture.co.uk

01

Ex4




02



03

Ax4


Bx4



04


Dx2

Fx1



05


Ax16



Cx2




Dx2




06

Bx6




07

Bx6




08




09







Bx4



10



11



12

