

HAPPINESS INSTALLATION



CAUTION

Parts are placed at the bottom of the product.

- If you have any questions with the product, please contact us by:
- **Email: customerservice@zoy-living.com**
(we will reply to you within 24 hours)

Assembly Instructions












CAUTION

DO NOT use any sharp objects to open plastic wrapped components as this may result damage to product or components .

Model: **CD0488AF21D**

Your recliner comes packaged in three box.
Carefully remove all of components from the packaging and set aside for assembly.


Package Contents

BOX 1 CD0488AF21D									
		A*1		B*1		C*1	D*1	L*2	N*2
									
E*1	M*2	M*1	F*1	G*1	H*1	O*1		I*1	
BOX 2 CD0488AF21D									
		L*1							
BOX 3 CD0488AF21D									
		J*1		K*1					

1 RECLINER ASSEMBLY - BODY SETUP


Step1:

Find a small bag inside the accessory box. Take out the power accessories from this small bag: (Power box (C), motor controller (E), power box power cable (B), massager controller (D), as well as the phone holder accessories: (holder (I), nut (F), fixing cap (G), phone cradle (H)). Use screws (M) to pass through the anti-tilt feet (L) and the base frame at the rear of the stand, then secure them with nuts (N)



Step2


Align the left and right armrest (J&K) inserts with the seat frame (A) insert, then push them downward. Make sure they are securely fastened before use.



2 RECLINER ASSEMBLY - BODY SETUP


Step3

The side piece is attached to the seat frame (A) via metal slides, and ensure that it is securely installed before use.



Step4


First, pass the Locking Cap G through the Holder I. Then, insert the rounded top end of the Holder I into the Phone Holder H, and tighten the Locking Nut G. Next, thread the Phone Holder I through the mounting bracket on the outside of the Left Armrest J, and tighten the Nut F. Tighten the nut (F) using an open-end wrench (O).



3 INSTRUCTIONS FOR USE - SIZE DIMENSIONS


Step5

Connect the massager power cord (M) to the backrest, connect the power box (C) to the power cable (B), and then connect the motor controller (E) and the massager controller (D) to the seat frame.




Step6


The product features a hidden cup holder.



4 INSTRUCTIONS FOR USE - SIZE DIMENSIONS



ASSEMBLY COMPLETED



Recliner

CD0488AF21D

⚠️ WARNINGS

1. Please check if the components of the chair are all included and can be used normally.
2. Assemble all components according to the instruction correctly before you connect the chair to the power.
3. Please DO NOT sit on the armrests or footrest to eliminate the risk of tipping over.
4. If the chair is damaged or doesn't match the website description, please send clear pictures of the product and label of the carton to our service team for further help.
5. If the recliner doesn't work, you may try the following measures for self-checking firstly:
 - a) check if all the cables are connected;
 - b) check if the light of transformer is on.

If the chair still doesn't work, please feed the information back to our customer service in time and we will help you solve the matter as soon as possible.

6. If you have any questions about our products, please contact us by:

Email: customerservice@zoy-living.com (we will respond to your inquiry within 24 hours)

