


USER MANUAL

TURBRO



Rotisserie Skewer Set

Model: RS01



KEEP THIS USER MANUAL FOR
FUTURE REFERENCE

CONTENTS

SAFETY INSTRUCTIONS 02

OPERATION TIPS 03

CARING FOR THE SKEWER SET 04

WARRANTY INFORMATION 05

SAFETY INSTRUCTIONS

- Read all instructions before using your skewer set.
- Remove the skewer set and store it in a dry place when not in use.
- This skewer set is not for use by children.
- Do not touch hot surfaces.
- Do not use the skewer set for other than intended use.

WARNING:

- Always wear heat-resistant grill mitts or gloves (conforming to EN 407, Contact Heat rating level 2 or greater) when handling a hot accessory.
- Do not use your skewer set directly on your burner.

CAUTION: Do not set your skewer set on a combustible surface, glass, or a surface that can be damaged by heat.

Failure to follow these Instructions may result in serious bodily injury or may result in a fire or an explosion causing damage to property.

OPERATION TIPS

Important: Always protect your hands from hot surfaces by wearing gloves or mitts.


Cooking Preparation

- Make sure that your skewer set is clean and ready to go.
- Lightly spray or apply cooking oil to the skewers to prevent food from sticking.

Assembly and Grilling Instructions

1. Slide the spit rod through the side plates **(A)**, tighten the thumb screws on both sides.


NOTE: Screws must touch a flat surface on the spit rod **(B)**.




2. Load food evenly onto skewers before assembly.

3. Insert the pointed end of the skewer into the hole of one side plate **(C)**.

Then pinch the end of the handle and secure it in both the slot and hole on the other side plate **(D)**.



(C)




(D)

OPERATION TIPS

Important: For best grilling results, please assemble all six skewers and ensure even meat distribution when using the set.

You are now ready for grilling.



(E)

Post-Cooking Safety

1. When the food is done, turn off the grill and rotisserie unit motor.
2. With heat-resistant gloves on, carefully remove the skewers from the grill.
3. Place the set in a safe and stable place to cool.

CARING FOR THE SKEWER SET

- Clean after each use. And be sure to clean the skewer set **after it has cooled down** to prevent scalding.
- Soak it in hot soapy water before you clean it.
- The rotisserie skewer set is dishwasher safe. However, handwashing using a mild detergent with a non-abrasive nylon brush or sponge is recommended to extend the life of the product.
- Thoroughly dry before storing.
- **With usage, the color of the stainless steel surface will begin to change. This is completely normal and will not change the cooking results.**

WARRANTY INFORMATION

TURBRO provides 1-year limited warranty service for Fireside Rotisserie Accessories, from the date of purchase, subject to the following conditions and limitations.

What is covered?

- Any alteration or misuse of the product will nullify this warranty.
- This warranty is non-transferable and is effective for the original buyer from the authorized seller only.
- This warranty is limited to the repair or replacement of part (s) proved to be defective in material or workmanship after said defect is confirmed by the manufacturer's inspection.
- The manufacturer may, at its discretion, fully discharge all obligations with respect to this warranty by refunding the wholesale price of the defective part (s).

What is not covered?

- Damage caused by the owner when attempting to fix or alter the product themselves.
- Damage caused by misuse, abuse, neglect, alterations, or unauthorized repair.
- Natural depreciation.

How to request warranty services?

To obtain the benefit of this warranty please leave a message online (www.turbro.com/pages/contact-us), or send an email to **support@turbro.com**. Our customer service will address your issue within 24 hours.

What will TURBRO do?

- Replace the item.
- Refund the item under certain circumstances.

TURBRO



 support@turbro.com

 www.turbro.com