


ASSEMBLY INSTRUCTION

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.

Do not fully tighten screws until fully assembled




Attention:


***Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product.





- VII. Power tools should not be used to assemble this product.




Parts List



Hardware List


A		Ø8x30mm	Wooden dowel	40 pcs
B		Ø6x35mm	Cam bolt	38 pcs
C		Ø15x11mm	Cam lock	38 pcs
D		Ø30mm	Sticker	38 pcs
E		Ø6x50mm	Screw	4 pcs
F		Ø4x12mm	Bolt	12 pcs
G			Corner code	2 pcs
H			Door stopper	2 pcs
I			Metal piece	2 pcs
J		Ø3x15mm	Bolt	8 pcs
K			Plastic wedge	8 pcs
L		Ø3x17mm	Screw	8 pcs
M		Ø8x5x16mm	Shelf support pin	8 pcs
N		4mm	Hex Key	1 pc
O		Ø4x18mm	Screw	4 pcs
P		Ø3.5x14mm	Screw	24 pcs
Q			Glue tube	1 pc
R			Hinge	4 pcs
S			Handle	2 pcs




Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Step 2





Step 3

A x 8	B x 6	C x 6	E x 4	N x 1
				
Ø8x30mm	Ø6x35mm	Ø15x11mm	Ø6 x50mm	4mm





Step 4

A x 4	B x 4	C x 4
		
Ø8x30mm	Ø6x35mm	Ø15x11mm





Step 5

A x 2	B x 2	C x 2
		
Ø8x30mm	Ø6x35mm	Ø15x11mm




Step 6

A x 4	B x 4	C x 4
		
Ø8x30mm	Ø6x35mm	Ø15x11mm




Step 7




Step 8

B x 10	F x 6	G x 2	H x 2	J x 4
				
Ø6x35mm	Ø4x12mm			Ø3x15mm




Step 9




A x 10
Ø8x30mm

C x 10
Ø15x11mm





Step 10




K x 8

L x 8
Ø3x17mm




Step 11

D x 38




Step 12

M x 8




Step 13





Step 14



I x 2	J x 4	O x 4	P x 12	R x 4	S x 2
	 Ø3x15mm	 Ø4x18mm	 Ø3.5x14mm		



Step 15



Step 16



Step 17

