








# Assembly Instructions


## Bench Grey Black

### Parts and Tools

|          |            |   |     |  |
|----------|------------|---|-----|--|
| <b>A</b> | 53005361-A |  | X 1 |  |
| <b>B</b> | 53005361-B |  | X 4 |  |
| <b>C</b> | 53005361-C |  | X 8 |  |
| <b>D</b> | 53005361-D |  | X 8 |  |
| <b>E</b> | 53005361-E |  | X 8 |  |
| <b>F</b> | 53005361-F |  | X 1 |  |

Echo Bench Grey Black

53005361



### Before Starting:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Always read the instructions carefully before beginning assembly to ensure that you have all required contents.
3. To prevent choking hazards, keep the packaging material out of reach of small children
4. Do not over tighten the bolts as this may damage the thread.
5. Use only vendor supplied hardware to assemble. Using unauthorized hardware could jeopardize the structural integrity of the item.
6. The use of power tools to aid in assembly is not recommended. Power tools can damage hardware and split wood.



ASSEMBLY REQUIRES  
TWO PEOPLE




15 MINUTE  
ASSEMBLY TIME



KEEP INSTRUCTIONS  
FOR FUTURE USE


## Bench Grey Black

1




Attach the Plastic Washers (C,D,E) onto the screws on Legs (B ).  
Assemble Legs (B) to the chair by turning counter clockwise until they are safely tightened.

2




Attach the Plastic Washers (C,D,E) onto the screws on Legs (B ).  
Assemble Legs (B) to the chair by turning counter clockwise until they are safely tightened.

3




Item is completed.



Adjust Pre-installed Levelers height to achieve balance



Adjust P



Pre-installed Levellevs heighe to achieve balance