

REQUIRED TOOLS

	STEL S		
Tools	Gloves	Table	Ladder
		Contraction of the second seco	() L
	Power drill	Screw drive	Tape Measure

ASSEMBLY TIPS

1. Clear a working area to allow access on all four sides. A raised work surface will make assembly easier. It is easier to install the wall panel on the table.

2. All parts are identified, so when working through the instructions page by page, the diagrams show where each part is positioned.

3. Before starting, to avoid any accidental injury, we recommend the use of gloves to protect your hands.

4. Please keep children away from your construction site.

 Most assembly can be completed by one person, but assistance may be needed when you reach the erection stage.

6. Please note: Some local government authorities have rules & regulations on shed installation, and you may need approval to erect this shed.

ASSEMBLY STEPS

1. Unpack all components from the carton and lay them out beside your work area. Check parts against the parts list.

Work through the assembly instructions page by page.

3. Once assembly is completed, place the shed in position and fix the anchor to the ground.

4. Clean up all metal pieces and screws.

K812parts list(A)


PART	NO.	QTY.
	W5-KD	2
	₩5-D	19
	K812-7L	2
	K812-7M	12
	K812-7R	2

K812parts list(B)


PART	NO.	QTY.
	W5-CD	4
}	W3-D	2
}	W2-HLD	1
}	W2-HRD	1
	K812-7MM	2
Esena	K812-1	2
	K812-1R	2
**	K810-2	2
	K812-2R	2
2009	K812-3	2
4	K812-3L	2
1923	K810-4	2
	K812-4R	2
	K812-5L	2
000	K812-5R	2
	K812-6L	6
	K812-6M	6
	K812-6R	6
-	K812-8	4
	K812-9L	2
	K812-9R	2
	K812-9M	2
	K812-10	2
	K812-10M	1

NO.	QTY.
UAD	2
C3	4
K812-11	8
DAD	2
DLAD	1
DRAD	1
DDA	4
DBD	4
GC	4
GE	2
T-F	4
DC	2
C2	4
DH	4
F1	508
F2	98
F3	32
V2	208
F4	4
GL	1
SL	80
M20	1
ST	2
	UAD C3 K812-11 DAD DLAD DLAD DDA DDA DDA DDA C2 GE T-F DC GE T-F DC C2 DH F1 F2 DH F1 F2 F3 V2 F4 GL SL M20


Shed top panels




Shed top frame




Door and Shed base








PART	NO.	QTY.
	K812-1	2
	K812-1R	2
	K810-2	2
	K812-2R	2
	T-F	4
	F1	36



PART	NO.	QTY.
]	W5-CD	4
- Contraction of the second se	F1	12








FI


FI

FI





PART	NO.	QTY.
	W5-D	12
	W3-D	2
	F1	108
9= 6	F2	16
		-


K812-4R	K810-4
K812-3L	K812-3
K812-3	K812-3
K810-4	K812-4R




PART	NO.	QTY.
	₩5-D	5
	F1	42
8=	F2	6












PART	NO.	QTY.
	K812-5L	1
	K812-5R	1
	F1	6
0	V2	6




PART	NO.	QTY.
	K812-5L	1
	K812-5R	1
E)	F1	6
0	V2	6







NO.	QTY.
C3	4
K812-11	8
F2	4
F1	16
	C3 K812-11 F2



PART	N0.	QTY.
Frank Street Str	K812-6L	6
Fringensteinen	K812-6R	6
Print	K812-6M	6
9 00 8	F2	48



PART	NO.	QTY.
9 00	F2	12




	PART	NO.	QTY.
K812-7R K812-7M K812-7M K812-7M K812-7M K812-7M K812-7M K812-7M K812-7M K812-7M		K812-7L	2
HALF CARPEND AND AND A THE PARTY		K812-7M	12
		K812-7MM	2
		K812-7R	2
	Ŷ	F1	148
	0	¥2	148

The two board splices in the center of the board are connected to the support beam K812-6L K812-6M K812-6R with F1 screws according to the installation illustration.


2


The top cover plate is installed as shown in the figure: Outside top cover (K812-7L K812-7R)

Mounted on top of the ventilation panel (K812-5L K812-5R) with the edges extending outwards by approx. 5 cm, the extension being the house eaves.





PART	NO.	QTY.
E	K812-10	2
	K812-10M	1
Ŷ	F1	8
0	V2	8







PART	NO.	QTY.
Balancia	K812-8	4
	K812-9L	2
	K812-9R	2
Real Property in the local division of the l	K812-9M	2
E	GC	4
Ø	GE	2
9	F1	36
0	V2	40
()m>	F4	4









PART	NO.	QTY.
	W5-KD	1
	W2-HRD	1
0-8	F2	2








PART	NO.	QTY.
	DH	4
æ	DC	2
Ŷ	F3	16
les .	GL	1
)-	F1	4



PART	NO.	QTY.
	DL	1
	DR	1
9	F3	16





PART	N	D. QTY.
	SI	80

