

OPTIMUS

INSTRUCTION MANUAL AND OWNER'S GUIDE

10" Metal Retro Fan

MODEL # F-6310



INFORMATION HOT LINE: If you have any questions or comments, please feel free to e-mail us at service@optimusent.com or call us at 1-888-672-5832. Our customer service representative will be happy to help you. E-mail is the best way to reach us.

PLEASE READ AND SAVE THESE INSTRUCTIONS

IMPORTANT INSTRUCTIONS:

Thank you for choosing an Optimus product. To ensure the best performance from this product, please read and save the following instructions.

WHEN USING ELECTRIC AL APPLIANCES, BASIC PRECUATIONS SHOULD ALWAYS BE FOLLOWED TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK AND INJURY.

- Read all instructions before using this product.
- Use this product only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electrical shock or injury, and may void the warranty.
- Do not plug the AC cord into the outlet until the product has been completely assembled.
- Use power source of the product according to electric nameplate under the base.
- Never operate the fan with a cracked or damaged fan blade or fan housing.
- Always unplug unit before assembly, disassembly, cleaning, moving or when not in use.
- To disconnect the product, turn the unit OFF, grip the plug and pull it from the wall outlet. Never pull the plug by the cord
- The use of attachments not recommended or sold by the manufacturer may cause injury.
- Avoid contact with moving parts.
- DO NOT operate the product with a damaged cord or plug. Discard the product after a malfunction or after being dropped or damaged in any manner.
- Do not hang or mount the product on a wall or ceiling.
- Do not operate the product in the presence of explosive and/or flammable fumes.
- Do not place the product or any parts near an open flame, cooking or other heating appliances.
- To avoid electric shock, do not immerse cord, plug or any parts of the product in water or spray with liquids.
- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the product by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the product.
- This product is intended for household use only and not for commercial or industrial use. Do not use outdoors.
- Always use on a dry level surface.
- Do not operate if the product housing is removed or damaged.
- **A loose fit between the AC outlet and plug may cause the plug to overheat.** Have a qualified electrician replace the outlet.
- This product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug fits into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact an electrician to replace the outlet. Do not defeat the safety purpose of the polarized plug.
- **NEVER** connect the product to any power sources other than a 120 volt alternating current polarized outlet.
- **Do not run cord under carpeting.** Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic areas where it might be tripped over.

WARNING:


- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT USE THIS PRODUCT WITH ANY SOLID-STATE SPEED CONTROL DEVICE.
- DO NOT INSERT FINGER OR ANY OBJECT INTO GRILL.
- TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, AND FULLY INSERT THE BLADES.
- UNPLUG THIS PRODUCT FROM THE POWER SUPPLY BEFORE SERVICE.
- IF THE POWER CORD IS DAMAGED, IT SHOULD BE REPLACED BY THE MANUFACTURER, ITS AGENT LICENSED OR QUALIFIED FOR SERVICE TO AVOID A HAZARD.

SAVE THESE INSTRUCTIONS

USER SERVICING INSTRUCTIONS:

This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse by following the servicing instructions below (follow product marking for proper fuse rating). If the replacement fuse also blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

- Grasp plug and remove it from the receptacle or other outlet device. Do not unplug by pulling on cord.
- Select a suitable tool such as a small flat screwdriver.
- Open the fuse access cover by sliding or prying it open.
- Carefully remove the fuse by prying it out from one end or by turning the fuse holder over.
- Risk of fire. **Replace fuse only with 2.5 Amp, 125 Volt fuse.** Gently press the new fuse into the slot at both ends. Do not press on the glass tube.
- Close the access cover until it is flush with the plug face.
- Do not replace the plug. It contains safety devices (fuse, AFCI, LCDI) that should not be removed. Discard the product if the plug is damaged.



Tips:

- Do not overexert when replacing the fuse or damage may occur.
- If it's hard to close the access cover, make sure the fuse is fully inserted.

CLEANING / MAINTENANCE INSTRUCTIONS:

During Season Care:

- Before cleaning, be sure to turn off and unplug the fan.
- Keep fan clean. Carefully wipe the unit with a soft, damp cloth.
- DO NOT immerse the fan in water and never allow water to drip into the motor housing. Please be very careful near the motor.
- Never use gasoline, benzene or thinner. This will damage the surface of the fan.
- After cleaning, be sure to dry the fan completely with a cloth or towel.


After Season Care:

- Before putting the fan in storage, clean thoroughly, cover with a plastic bag and store it in a cool and dry place. We recommend using the original or a properly sized box.

Maintenance:

- Do not attempt to repair or adjust any electrical or mechanical functions of this unit. Doing so will void the warranty. Return to Optimus for service.
- If the power cord is damaged, the unit must be discarded to avoid a hazard.
- This product must be disposed of properly according to local authority. By recycling, you help save the environment.

OPERATING INSTRUCTIONS:



Operation

1. Ensure the fan is turned off before plugging into the mains socket. Place the fan on a level and dry surface.
2. Only connect the fan to a suitable mains socket.
3. The fan has two speeds. Move the Speed Control Switch to your desired speed. There are 3 settings – O (off), I (low) and II (high).
4. Move the Speed Control Switch to "O" position and unplug the fan after use.

Specification

Rated voltage : 120V ~ 60HZ

Power consumption : 25 watts

WARRANTY

For your own records, staple or attach your sales receipt to this manual. Please also write the store name/location and date purchased below.

STORE NAME/LOCATION: _____

DATE PURCHASED: _____

ONE (1) YEAR LIMITED WARRANTY: (SAVE THIS WARRANTY INFORMATION)

Optimus Enterprise, Inc, warrants to its customers and /or consumer of this electric fan and the parts thereof will be free from defect in material and workmanship, under normal use, for a period of one (1) year from the date of initial purchase. The warranty does not apply to repairs necessitated by damage, misuse, abuse or alteration and to any repairs of merchandise not used within the United States unless otherwise prescribed by law. Optimus Enterprise, Inc, shall not be liable for any personal injury, property damage or any incidental or consequential damages of any kind (including water damage) resulting from malfunctions, defects, misuse, improper installation or alternation of this product. This warranty is the only warranty extended by Optimus Enterprise, Inc, to its original customers and /or consumers purchasing fan, Optimus Enterprise, Inc, disclaims all other warranties, expressed or implied, that arise by the operation of law, specifically including the implied warranties of merchantability and fitness for a particular purpose. Optimus Enterprise, Inc, shall not be liable for any incidental or consequential damage, which may have resulted from any alleged breach of warranty. Some states do not allow limitations on how long implied warranty lasts or the exclusion or limitation of consequential damage, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights you may also have other rights which vary from state to state. Should the fan fail during the warranty period, the owner should:

- Within the first 30 days from date of purchase, the store from which you purchased your Optimus product should replace this product if it is defective in material or workmanship (provided the store has in-stock replacement).
- Within the first 12 months from date of purchase, Optimus Enterprise, Inc, will repair or replace the product if it is defective in material or workmanship providing it is returned to Optimus Enterprise, Inc. with freight prepaid, with evidence of purchase date (cash register receipt) together with USD \$30.00 (within continental US) CHECK OR MONEY ORDER for handling and return packaging/shipping charges.

IMPORTANT: ANY REPAIRS SHOULD BE PERFORMED BY AN AUTHORIZED SERVICE REPRESENTATIVE. DO NOT ATTEMPT TO REPAIR THIS FAN YOURSELF. DOING SO MAY VOID YOUR WARRANTY. PLEASE RETAIN THIS WARRANTY AND SALES RECEIPT TO INSURE YOUR PRODUCT WARRANTY.

RETURN INSTRUCTIONS:

Your warranty depends on your following these instructions if you are returning the unit

more than 30 days after the date of purchase:

- Carefully pack the fan in the original container or a suitable container to avoid damage in shipping.
- Seal the carton. Address an envelope as follows:
Optimus Enterprise, Inc.
2201 E. Winston Road, Unit #J
Anaheim, CA 92806
- Inside the envelope, enclose your name, full address with zip code, daytime phone number, evidence of purchase date (cash register receipt) AND A CHECK OR MONEY ORDER for handling and return packaging/shipping charges. Please also include a brief explanation of the problem you are having with the unit.
- Optimus Enterprise, Inc. recommends you ensure the package as damage in shipments is not covered by your warranty.
- All shipping/ handling charges must be prepaid by you (as noted as above).