



ASSEMBLY INSTRUCTIONS


BLACK HOME THEATRE OAK HOME THEATRE CHERRY HOME THEATRE MAPLE HOME THEATRE PROMENADE HOME THEATRE CAPPUCCINO HOME THEATRE



1. REMOVE ALL PARTS AND SEPARATE THEM INTO GROUPS AS LISTED. REMOVE ALL PACKING MATERIALS, STRAPS, STAPLES, ETC. IT IS RECOMMENDED YOU OBTAIN AN ASSISTANT FOR SAFETY AND EASE OF ASSEMBLY.
2. PLACE THE TOP ASSEMBLY (PART 1) UPSIDE DOWN ON A SMOOTH PADDED SURFACE, SUCH AS THE PACKING FOAM.
3. ATTACH ALL 4 LEGS (PART 2) TO THE TOP ASSEMBLY BY PLACING THE BOLTS AND WASHERS (PARTS 3,4,5) THROUGH THE CORNER BLOCKS, AS SHOWN IN DIAGRAM A. HAND THREAD FIRST AND DO NOT FULL TIGHTEN YET.
4. ATTACH THE METAL "L-BRACKET" (PART 8) TO THE BOTTOM OF THE LEGS USING THE ALLEN HEAD SCREWS (PART 9). ALLEN HEAD WRENCH PROVIDED (PART 6).
5. FIT THE SHELF ASSEMBLY (PART 7) UNDERNEATH AND ATTACH TO THE LEGS WITH THE REMAINING ALLEN HEAD BOLTS.
6. NOW GO BACK AND FULLY TIGHTEN ALL BOLTS. ASSEMBLY IS NOW COMPLETE.
7. IT IS RECOMMENDED TO USE A NAME BRAND FURNITURE POLISH AND A SOFT CLEAN CLOTH, TO CLEAN AND PROTECT THE WOOD SURFACES.

THANK YOU FOR YOUR PURCHASE!

CHAIR SIDE TABLE



PART#	DESCRIPTION	QTY
1	TOP ASSEMBLY	1
2	LEG	4
3	WASHER	4
4	LOCK WASHER	4
5	BOLT	4
6	ALLEN HEAD WRENCH	1
7	SHELF ASSEMBLY	1
8	L-BRACKET	4
9	ALLEN HEAD SCREW	8