

Assembly Guide




If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-950-4782.

Our customer service experts are trained to provide step-by-step instruction and can easily replace any missing or damaged parts.

Representatives are available Monday-Friday from 8:30 a.m. to 7:30 p.m. (ET)

72 W Hutch



Lot Code #

Part Number A191596A

Keep manual for future reference.

For best results, keep these tips in mind:

- ① We know you want to finish this assembly as quickly as possible, but trust us: you'll have a better experience if you take it one step at a time.
- ② Give yourself some room to work near where you want the fully assembled product.
- ③ If your floor isn't carpeted, assemble this product on the empty carton to avoid scratching.
- ④ Do you have a friend who owes you a favor? Some steps may go a little easier with a second set of hands.

DOs

- ✓ Use a #2 Phillips head screwdriver (or other handheld tools as indicated)
- ✓ Wear safety glasses at all times during assembly
- ✓ Carefully follow the instructions in this guide and complete all steps in order
- ✓ Give us a call if you're having trouble with a particularly tricky step

DON'Ts

- ✗ We know power tools are quick and easy, but you shouldn't use them when assembling this product (unless otherwise specified)
- ✗ Never move your furniture with items inside or resting on the surface
- ✗ Do not attempt to use this product before all steps have been completed



Watch assembly videos right on your phone or computer!



Some steps include QR codes that link to helpful videos. Watch out for the icon below! Simply open up your smartphone camera to scan the code.

(Users of older smartphones may need to install a QR Reader.)

SCAN HERE



FOR VIDEOS

Or visit <https://www.bushbusinessfurniture.com/CustomerService/HowtoAssemble.aspx>

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Warning	Do	Don't	Why it's important
Serious injury may occur.	- Assemble following all instructions using all indicated parts and hardware provided. - Attach hutch only as described in the instructions. - Verify furniture is stable on it's own. - Only place against a permanent wall structure at least as tall as the hutch or place back-to-back with hutch of same size.	- Do not move unit when loaded. - Do not load with a television or other heavy equipment. - Do not exceed the maximum load limits stated in the instructions. - Do not allow children to climb, or hang on furniture.	Improper assembly, use or loading can lead to product instability, tip-over or collapse.

Advertencia	Hacer	No	Por qué es importante
Se pueden producir lesiones graves.	- Ensamble siguiendo todas las instrucciones utilizando todas las piezas y ferretería indicados provistos. - Conecte la conejera solo como se describe en las instrucciones. - Verifique que los muebles sean estables por sí mismos. - Solo colóquelo contra una estructura de pared permanente al menos tan alta como la conejera o colóquelo espalda con espalda con una conejera del mismo tamaño.	- No mueva la unidad cuando esté cargada. - No cargue con un televisor u otro equipo pesado. - No exceda los límites máximos de carga establecidos en las instrucciones. - No permita que los niños se paren, trepen o cuelguen de muebles.	El ensamblaje, uso o carga inadecuados pueden provocar inestabilidad del producto, vuelco o colapso.



IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.


Avertissement	Faire	Ne le fais pas	Pourquoi c'est important
Des blessures graves peuvent survenir.	• Assemblez en suivant toutes les instructions en utilisant toutes les pièces et le matériel indiqués fournis. • Fixez la huche uniquement comme décrit dans les instructions. • Vérifiez que les meubles sont stables par eux-mêmes. • Placer uniquement contre une structure murale permanente au moins aussi haute que la huche ou placer dos à dos avec une huche de même taille.	• Ne déplacez pas l'unité lorsqu'elle est chargée. • Ne chargez pas avec un téléviseur ou un autre équipement lourd. • Ne dépassez pas les limites de charge maximale indiquées dans les instructions. • Ne laissez pas les enfants grimper ou s'accrocher aux meubles.	Un assemblage, une utilisation ou un chargement incorrects peuvent entraîner une instabilité du produit, un renversement ou un effondrement.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Fasteners are shown actual size.


H28917 [8]
(Silver) #6 x 1/2"




H171556 [43]
Quickfit TL4




H108982 [4]
(Silver) M4 x 20mm



H181468US [43]
KD Cam3000




H23682 [8]
(Black) #10 x 1"




H38169 [8]
Wood Dowel 8 x 30




H107572 [1]
#8 x 1-1/2"



H181419 [1]
Toggle Bolt













H181434 [1]
#10 x 2"



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Hardware not to scale.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 1

Prepare Doors

A191596A


H126359



[4]

Hinge


H77351



[1]

Bumper (4) per pack

H191524



[2]

Pull

H108982

(Silver)




[4]

M4 x 20mm


H28917

(Silver)



[8]

#6 x 1/2"




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 2

Prepare Panel



A191596A

H171556



Quickfit TL4

[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 3

Assemble Panels

A191596A

Scan QR Code to
Watch Video on:



How to Tighten
KD Cams

H181468US





KD Cam3000

[2]



Cover Cap

[2]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 4

Prepare Panel



A191596A

H171556



[7]

Quickfit TL4



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 5

Assemble Panel


A191596A

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

H181468US





KD Cam3000

[4]



Cover Cap

[4]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 6

Prepare Assemble


A191596A

Scan QR Code to
Watch Video on:



How to Tighten
KD Cams


Team Lift



H181468US




[3]



[3]

Cover Cap




H171556



[5]

Quickfit TL4




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 7

Prepare panels

A191596A

H126364



[4]


Mounting Plate

H38169



[4]

Wood Dowel 8 x 30



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 8

Assemble Panels

A191596A

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

H181468US





KD Cam3000

[2]



Cover Cap

[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 9

Assemble Panel


A191596A

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams


Team Lift



H181468US



KD Cam3000




Cover Cap


[3]

[3]


1





2



3




4




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H171556



Quickfit TL4

[5]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 11

Assemble Panel


A191596A

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

Team Lift




H181468US





KD Cam3000

[5]



[5]

Cover Cap




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


STEP 12

Prepare Panel



A191596A



H171556




[3]





Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H171556



Quickfit TL4

[7]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 14

Assemble Hutch


A191596A

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

Team Lift




H181468US



KD Cam3000


[4]




Cover Cap

[4]


1






2



3




4




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H171556



Quickfit TL4

[7]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 16

Assemble Panel

A191596A

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

H181468US



KD Cam3000



Cover Cap

[4]



[4]

1


2

3


4




Team Lift



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




H38169




Wood Dowel 8 x 30

[4]





Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

H171556



Quickfit TL4

[7]



STEP 19


Assemble Panel

A191596A

Scan QR Code to
Watch Video on:



How to Tighten
KD Cams



H181468US





KD Cam3000



Cover Cap

[4]

[4]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 20


Install Hardware

A191596A

Scan QR Code to
Watch Video on:



How to Tighten
KD Cams



H181468US





KD Cam3000

[12]



Cover Cap

[12]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


STEP 21

Install Hutch

A191596A




H23682
(Black)





[8]



H85966



[2]



Safety glasses
Gafas de seguridad
Lunettes de protection



Drill (8) 1/8" holes 3/4" deep.

Perfore (8) agujeros de 3mm a 19mm de profundo.

Percer (8) trous de 3mm de diamètre et 19mm de profondeur.

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Secure unit to the wall with a tip-over restraint.

Unidad de seguro a la pared con un sistema de retención de un vuelco.

Fixer l'unité au mur avec un dispositif de retenue renversement.

1. Place unit in desired location.
2. Locate wall stud nearest unit center. **FIG A**
3. On wall, mark center of stud location 1" below top of unit. **FIG A**
4. If a wall stud cannot be located mark hollow wall at unit center. **FIG A**
5. On back of unit, mark corresponding location 3/8" below top of unit. **FIG B**

1. Coloque la unidad en el lugar deseado.
2. Localice pie derecho de pared centro de unidad más próxima.
3. En la pared del, marque el centro de la ubicación del montante 1 "abajo la parte superior de la unidad.
4. Si un poste de la pared no se puede localizar marcar pared hueca en el centro de la unidad.
5. En el dorso de la unidad, marque la ubicación 3/8 correspondiente abajo la parte superior de la unidad.

1. Placez l'unité à l'endroit désiré.
2. Localiser centre d'unité la plus proche de la paroi Stud.
3. Sur le mur, centre de emplacement du montant 1 "ci-dessous dessus de l'appareil de la marque.
4. Si un montant de mur ne peut pas être situé marquer mur creux au centre de l'unité.
5. Le dos de l'appareil, marquer l'emplacement 3/8 correspondant ci-dessous dessus de l'appareil.

FIG A

Mark back within 6" (150mm) of center.

Marcar de vuelta dentro de 6" (150mm) de centro

Mark dans les 6" (150mm) de centre.






FIG B



Have an assembly question or need a replacement part? Just call

1-800-950-4782, we are here to help.

WALL STUD ATTACHMENT




Drill 1/8" hole 2" deep at mark on wall.

Taladro 1/8 "agujero 2" de profundidad en la marca en la pared.

Perçer 1/8 "trou de 2" de profondeur à la marque sur le mur.


H181434



#10 x 2"

[1]


H181412




[1]

Connecting Plate

H181412




Drywall
Paneles de yeso
cloisons sèches



Wood stud
Montante de madera
Stud bois

HOLLOW WALL ATTACHMENT




Drill 1/2" hole 1" deep at mark on wall.

Taladro 1/2 "agujero 1" de profundidad en la marca en la pared.

Perçer 1/2 "trou de 1" de profondeur à la marque sur le mur.


H181419



[1]

Toggle Bolt

H181412



[1]

Connecting Plate

H181412




Drywall
Paneles de yeso
cloisons sèches



Pull while tightening
Jale mientras aprieta
Tirer tout en resserrant


Drywall
Paneles de yeso
cloisons sèches



Have an assembly question or need a replacement part? Just call

1-800-950-4782, we are here to help.


H107572



[1]


#8 x 1-1/2"

H181412



[1]


Connecting Plate



Drill 1/8" hole 1" deep at mark on unit.

Taladro 1/8 "agujero de 1" de profundidad en la marca de la unidad.



Perçer 1/8 "trou 1" de profondeur à la marque sur l'unité.



H181411

[1]


Nylon Cable Tie



Pull to verify lock

Tire para verificar cerradura

Tirez pour vérifier serrure



Correct
Correcto
Corriger

Use replacement cable tie with minimum breaking strength of 120lbs.

Utilice reemplazo empaque Cable con resistencia a la rotura mínima de 120 libras.

Utilisez remplacement Attache de câble avec une force de rupture minimale de 120 lbs.




Have an assembly question or need a replacement part? Just call

1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:



How to Adjust
Door Hinges



Tighten
Apretar
Serrer


Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 26

Insert Panel

A191596A


H23604



Shelf Pin


[4]

H126396




Shelf Pin Sleeve

[4]



4x




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Scan QR Code to
Watch Video on:



How to Clean
the Surface

Gently clean surfaces with a damp sponge eraser.




Congratulations! You are all done. If
you have any questions or concerns,
please call.

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

OFH172BW

A	W191597	1
B	W191598	1
C	W191599	1
D	W191600	1
E	W191601	1
F	W191602	2
G	W191603	1
H	W191604	2
J	W191605	1
K	W191606	1
L	W191607	1
M	W191608	1
N	W191589	2

H191633




[43]

Cover Cap

OFH172SG

A	W193241	1
B	W193242	1
C	W193243	1
D	W193244	1
E	W193245	1
F	W193246	2
G	W193247	1
H	W193248	2
J	W193249	1
K	W193250	1
L	W193251	1
M	W193252	1
N	W193229	2

H92521




[43]

Cover Cap

OFH172MH

A	W193095	1
B	W193096	1
C	W193097	1
D	W193098	1
E	W193099	1
F	W193100	2
G	W193101	1
H	W193102	2
J	W193103	1
K	W193104	1
L	W193105	1
M	W193106	1
N	W193083	2

H83021




[43]

Cover Cap

OFH172SO

A	W193168	1
B	W193169	1
C	W193170	1
D	W193171	1
E	W193172	1
F	W193173	2
G	W193174	1
H	W193175	2
J	W193176	1
K	W193177	1
L	W193178	1
M	W193179	1
N	W193156	2

H193368



[43]

Cover Cap