MANUAL INSTRUCTION

10' x 10'Gazebo



ATTENTION

- Please check the parts list and hardware list carefully to make sure you've received all parts.
- 2. Be sure not to overtighten during installation, and never tighten all screw components until they are all installed.
- 3. If there are any missing parts, please contact us with-the missing part and the missing part number, we'll resend them to you ASAP.
- 4. If there are any damaged parts, please contact us with clear picture or clear video, we'll offer you the best solution after confirming it.


△ WARRANTY AND RETURN


- We offer 1 year warranty and free replacement for all damaged or defective parts you received. Check the condition of your package once upon the delivery.
- If you have any questions, please contact our customer service immediately.

(1) CONTACT INFORMATION

- If you order our product on Amazon /Walmart /Wayfair etc. Please log in your Amazon/Walmart/Wayfair account to contact us.
- If you order our product on Shopify, please contact us at service @meissalivve.com, our service team will reply within 24 hours.

TOOLS & EQUIPMENT






Screwdriver






Component labeling of Gazebo




A-SET A SOLID SURFACE PRIOR TO ASSEMBLY


1-Concrete/tiled wall




2-Concrete/tiled floor



B-USE THE RIGHT SCREWS FOR YOUR SURFACE



1-Concrete/tiled surface (floor & wall) 2-Not recommended wooden surface




The screws and masonry anchors supplied with the kit are suitable for concrete /tiled floor & wall fixing only. Note: please do not use wooden surface (floor & wall)


Please consult with an expert regarding which fasteners are suitable for other surfaces types (not supplied).

C-CUSTOM THE NUMBER OF POLES REQUIRED

1-Heavy snow load expected




2-Light or no snow load expected



In case of expected heavy snow load. install all supplied poles. Increase the installation of connecting beam.

In case of expected light or no snow load, connecting beam not be installed.

PARTS Packing List of Box A



4 PCS


2 PCS


PARTS Packing List of Box A























PARTS Packing List of Box A







PARTS Packing List of Box B



I HARDWARE




1 Rear Column Installation: Repeat assembly 2 times.



PART	NO.	QTY.	PART	NO.	QTY.
	Α	2	91111111	1	16
	С	2	8 <u> </u>	4	4
	N	2	•	6	4
٨	Р	6	0	7	20


PART	NO.
	11
B	12

2 Front Column Installation: Repeat assembly 2 times.




PART	NO.	QTY.	PART	NO.	QTY.
	Α	2	@	4	4
	В	2	8	6	4
	Ν	2	0	7	20
٥	Р	4		11	
91111111	1	16	B	12	

3 Cross beam Installation: Repeat assembly 2 times.




4 Assemble the 2 front columns from step 2 and 1 crossbeam from step 3.



PART	NO.	QTY.	PART	NO.	QTY.	PART	NO.
	L	1	•	5	8		11
1	М	1	0	7	8		
(1)	1	8		10			


5 Assemble the two rear columns from step 1 and the crossbeam from step 3.




PART	NO.	QTY.	PART	NO.	QTY.	PART	NO.
	K	2		5	8		10
(I)	1	4	0	7	4		11


Top Vertical Beam Installation: Repeat 6 times. Please tighten the screws.







7 Top Vertical Beam Installation: Repeat 6 times.






9 Top Horizontal Beam.







11 Front and rear column connecting beam Installation: Repeat 2 times.



17


PART	NO.	QTY.
	i	4
	Т	2
91111111	1	8
0	7	8
	11	






Top panel installation: Repeat 5 times.

Note: Panel has writing on one side of protective film. Place writing inward, other side towards sun. Remove film before use.




PART	NO.	QTY.
	W	10
	G	5

Note: Panel has writing on one side of protective film. Place writing inward, other side towards sun. Remove film before use.





Please follow the order from left to right, first use part "H" to clamp the top panel, and then use part "V" to fix its left end. Install in the order of "H" "V" "H" "V"...




PART	NO.	QTY.
	V	12
	Н	10

PART	NO.	QTY.
9111111	1	12
0	7	12


PART	NO.
	11





PART	NO.	QTY.
•	8	24

Install the LED solar lights in the position as shown below; the solar lights have 9.8 ft of moving space.





PART	NO.	QTY.
7.5P	9	2