



## Use and Care Manual

# PREMIUM WOOD SHELVING KIT

- Use a soft, clean cloth that will not scratch the surface when dusting.
- Using solvents of any kind on your shelving may damage the finish.
- Never use water to clean your shelving as it may cause damage to the finish.
- Always use coasters under beverage glasses and flowerpots.
- Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.
- Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- Stains or marks from crayons or ink markers will be difficult to remove.
- It is recommended to keep the shelving in a climate controlled environment. Extreme temperature and/or humidity changes can cause deformation in the wood.