


ASSEMBLY INSTRUCTIONS

SKU-N724P353565

END TABLE






Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Before Installation








Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- . We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- . Please do not over tighten screws or bolts until the assembly is completed.
- . Keep children and animal away from the work area, small parts could choke if swallowed.
- . Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Cam Lock Assembly Instructions
















		Diagram A Insert Cam Bolt into hole as shown in diagram A.	
		Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.	
		Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.	
			Connect the panels together.
			Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
			To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View














Identifying the Hardware-Identify the hardware using the illustrations below.

Part List - N724P353565


1	 Front top panel- 1pc	2	 Top rear panel - 1pc
3	 Side Panel (L) - 1pc	4	 Side Panel (R) - 1pc
5	 Mid Panel Rear - 1pc	6	 Bottom Panel Rear - 1pc
7	 Adjustable Shelf - 1pc	8	 Mid Front Bar - 1pc
9	 Rear frame - 1pc	10	 Bottom Frame - 1pc
11	 Door Cabinet - 1pc	12	 Top drawer panel - 1pc
13	 Drawer Face - 1pc	14	 Drawer Side Panel (L) - 1pc
15	 Drawer Side Panel (R) - 1pc	16	 Drawer Panel Rear - 1pc

Hardware List - N724P353565



A  ø6x35mm	B  Ø14.5x9.5mm	C  ø8x30mm
Three in one bolts (24pcs)	Three in one lock (24pcs)	Wood dowel (22pcs)
D  40x18x14x14x1.5mm	E  ø6xø3x12mm	F  Ø29x24mm
Hinge (2pcs)	Flat head screw (12pcs)	Handle (2pcs)
G  ø5/32"x28mm	H  ø5/32"x38mm	I 
Handle screw (1pc)	Handle screw (1pc)	USB power socket (1pc)
J  ø7xø3.5x15mm	K  55x40x1.5mm	L  ø7xø3.5x15mm
Flat head screw (2pcs)	6-hole leaf hinge (2pcs)	Flat head screw (12pcs)
M 	N 	O  ø6xø3x12mm
Magnetic Catch (1pc)	Strike Plate (1pc)	Flat head screw (4pcs)
P  Ø6.2x31x19x16mm	Q  Ø7.5xØ3.5x32mm	
Shelf Support (4pcs)	umbrella head screw (8pcs)	

STEP: 1

A






24PCS




STEP: 2

B	C
	
4PCS	5PCS





STEP: 3

B	C
	
4PCS	5PCS





STEP: 4

B	C
	
4PCS	4PCS





STEP: 5

B	C
	
4PCS	4PCS





STEP: 6




B		C	
4PCS		4PCS	


STEP: 7




I		J	
1PC		2PCS	

STEP: 8




D		E	
2PCS		6PCS	

STEP: 9





E	
6PCS	


STEP: 10

P**4PCS**


STEP: 11

K**2PCS****L****6PCS**



STEP: 12




STEP: 13




STEP: 14


Q**8PCS**

STEP: 15


B**4PCS**

STEP: 16

F		H	
1PCS		1PCS	



STEP: 17



STEP: 18

