




MARATHON

24 HOUR COMPACT DIGITAL COUNTDOWN TIMER WITH COUNT-UP & CLOCK FEATURE



OPERATING INSTRUCTIONS

- Setting the Clock**
Slide the side switch to "CLOCK". Press the "HR", "MIN", and "SEC" buttons to set the desired time. Press and hold each button to advance through the values rapidly.
- Setting the Time Format**
Slide the side switch to "CLOCK". Press and hold "CLEAR" for approximately 2 seconds to change between 12-hour and 24-hour time format.
- Count Up Function**
Slide the side switch to "COUNT UP". Press "START" to begin counting up. Press "STOP" to temporarily stop timing. Press "START" to continue counting up. Press "CLEAR" to reset the time to 0:00:00.
- Setting the Timer**
Slide the side switch to "TIMER". Press the "HR", "MIN", and "SEC" buttons to set the desired time. Press and hold each button to advance through the values rapidly.
Time Up Function
Once the timer reaches 0:00:00, an alarm will sound. The timer will begin to count up from 0:00:00, indicating the amount of time that has elapsed since the alarm.
- Setting the Preset Time**
Slide the side switch to "TIMER". Press the "HR", "MIN", and "SEC" buttons to set the desired time. Press and hold each button to advance through the values rapidly. Once the desired time has been set, press "MEMORY" to save the time.
Deleting the Preset Time
Slide the side switch to "TIMER". Press "MEMORY", then press "CLEAR" to delete the saved time.
Viewing the Preset Time
Slide the side switch to "TIMER". Press "MEMORY" to view the preset time.

WARNING: Choking hazard - Small parts. Not suitable for children under 3.

WARRANTY

Marathon Watch Company warrants this item to be free from defects in material and workmanship under normal use in accordance with care and usage instructions for 2 years from date of purchase from an authorized retailer. This warranty excludes damage from misuse, abuse or any irregular application. Return the item to us properly packaged accompanied with the original bill of sale. Please contact Customer Service at 1-800-822-4329 to obtain the shipping address. If we confirm a defect, we will replace it with the same item or one of similar value and return it to you at no charge.


Marathon Watch Company Ltd.
www.MarathonWatch.com
Customer Service: 1-800-822-4329

Marathon Watch Company Ltd.
www.MarathonWatch.com

★ Designed in Canada / Conçu au Canada
Made in China / Fabriqué en Chine

2 YEAR
warranty
Garantie
de 2 ANS





Pressez et maintenez “HR”, “MIN”, ou “SEC” pour actualiser l’heure.

Pressez et maintenez “HR”, “MIN”, ou “SEC” pour le minutage. Pressez 5 secondes retentira lorsque la minuterie aura terminé son opération.

Le chiffre de 0:00:00, indiquant combien de temps s’est écoulé depuis l’alarme.

Pressez “MIN”, ou “SEC” pour l’heure désirée et pressez ensuite “MEMORY”.
Glissez jusqu’à « TIMER » et pressez « MEMORY » pour rappeler l’heure.

Appuyez sur le bouton “PRÉ-ALARMER”.
Appuyez “MEMORY”. Pressez “CLEAR” pour annuler l’heure pré-réglée.

Appuyez sur le bouton “COUNT UP », pressez « START » pour commencer le comptage vers le haut.
Appuyez sur le bouton “COUNT DOWN » pour compter temporairement et « START » pour continuer le comptage. Pressez « CLEAR » pour réinitialiser le comptage à 0:00:00.

Appuyez sur le bouton “LOCK”, pressez et maintenez “CLEAR” pendant deux secondes pour verrouiller le timer pendant 24 heures ou vice versa.