

Thank you for your purchase!



# Heated Folding Stadium Seat

## Assembly Instructions:

### Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly. A Phillips screwdriver is required for assembly (not included).

### Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. Do not use any sharp objects to open plastic wrapped components as damage to product or components may result.

### Warning:

**CHOKING HAZARD** - Small Parts. Adult Assembly Required.

### DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

## To Use With Armrests:



**01** Press down the hinges from the back until you hear them lock into place.



**02** Place one hand on the seat and pull the backrest up until you reach the desired back angle.



**03** Put one hand on the seat and pull the backrest forward according to your desired angle. There are 6 adjustable angles for your choice.



**04** Secure the seat by the straps and buckle.

## To Use Without Armrests:




**01** Press down the hinges from the front until you hear them lock into place.



**02** Place one hand on the seat and pull the backrest up until you reach the desired back angle.



**03** Put one hand on the seat and pull the backrest forward according to your desired angle. There are 6 adjustable angles for your choice.



**04** Secure the seat by the straps and buckle.

## How to Lay Flat?



**01** Push forward to release the backrest.



**02** Lay flat the seat back.



**03** Put the seat on your back and go anywhere you want.

## How to Heat?



**01** Unzip arm pouch and remove switch and USB.



**02** Plug the USB cable into a power bank or any place with a USB power port.



**03** Heat functions of the back and seat are controlled separately.

## Quality and Safety Guidelines

- Please follow the static and dynamic weight capacity limits provided on this item. If you are unsure of the weight capacities for this product, email us [info@hugoboss.com](mailto:info@hugoboss.com).
- Please use this item on a stable, level surface only. Bottom of the chair should contact the seating surface when in use. Do not use this item if any instability is detected.
- To prevent accidental tipping, do not forcefully push backward or forward while seated. Do not slide chair backwards, forwards or sideways while seated in chair.
- For maintenance instructions and replacement parts, please email us [info@hugoboss.com](mailto:info@hugoboss.com).
- This item is intended for sitting only, do not climb or stand on this item.
- To prevent pinching or crushing injuries, ensure fingers are not in or near any part of the folding mechanism.
- This chair was designed for indoor or outdoor use but care should be taken to prevent prolonged exposure to wet weather.
- For product longevity, product safety and product integrity, protect from wet and humid weather and store indoors in a dry location.