


ASSEMBLY INSTRUCTIONS

Solid Wood Widened Coat Hanger

Model TXG405



Before You Start

- Confirm all parts are complete.
- Assemble correctly and safely.
- Keep small parts away from children.

Manual Includes

- Parts checklist
- Hardware identification
- 5 clear assembly steps
- Care and safety guidance

Important Use the product only for its intended purpose. Place it on a flat, stable surface before loading items.

Parts & Hardware Checklist

Verify every component before assembly.

No.	Part Name	Specification / Note	Qty
1	Short upper side panel	740 mm	1
2	Long upper side panel	810 mm	1
3	Lower side panel	800 mm	2
4	Hanging post	-	5
5	Crossbar	-	1
6	Round rod	-	1
7	Metal sleeve	-	2
8	Chassis / base plate	-	1
9	Hanging post screws	-	5
10	Straight repair screws	Contains 1 spare piece	11
11	Metal set screws	-	4
12	Hex wrench	-	1

Pre-assembly Instructions


- Confirm the product parts are complete before assembly.
- Follow the manual and assemble the product correctly and safely.
- Keep the assembled parts and small hardware out of children's reach.

Assembly Steps 1-3

Build the upper posts first, then connect the lower panels.


1 Install the hanging posts

Pass No. 9 hanging post screws through the large countersunk holes on the sides of the two upper side panels, then lock them with No. 4 hanging posts.




2 Attach the metal sleeves

Put each metal sleeve in place and tighten it with No. 11 metal set screws.



3 Connect the lower side panels

Connect No. 3 lower side panels to the two metal sleeves and lock them with No. 11 metal set screws.




Assembly Steps 4-5

Install the crossbar, rod and chassis to complete the rack.


4 Install the crossbar and round rod

Use No. 10 straight screws to install the No. 5 crossbar and No. 6 round rod. Install the other side panel and align all screw holes before tightening.



5 Secure the chassis

Secure the bottom of the chassis and side panels with No. 10 straight screws. Tighten all fasteners after the frame is aligned.



Installation Completed

Place the rack on a flat surface and confirm it stands upright without wobbling before use.

Care, Use & Safety

Follow these rules to maintain stability and product life.

Maintenance

- Stop using the product if it is damaged or deformed during use.
- After about 3 months of use, check the parts regularly. If any safety hazard is found, stop using it.
- Do not repair or modify this product by yourself.

Use Notes

- Do not sit or jump on this product.
- Do not use the rack as a platform to pick up items, especially for children.
- Use it only for its intended purpose.

Stability

- Use the product on a flat surface to help prevent overturning, deformation and damage.
- Do not overload one side. Distribute weight evenly across the rack.

After-sales

- For quality problems, missing accessories or installation difficulties, contact the store where the product was purchased.
- Dispose of packaging materials appropriately.

Keep This Manual

Store these instructions for future reference, reassembly, or hardware identification.