

Baby Slide

USER MANUAL

WARNING

1. Assembly by an adult. Install with this side **AWAY** from child.
2. Children must be used under the guardianship of adults.
3. The range age of use of this product is 1- 8 years.
4. Only used by one child who does not exceed 60 kgs.
5. Only for domestic use.
6. This activity toy is usually suitable for indoor use or temporary outdoor use.
7. Use only with the mechanism securely engaged. Do not expose the product to direct sunlight for a long time.
8. Keep the assembly and installation instructions for further reference.
9. When the product is damaged, broken or disassembled, stop using the product.
10. A recommendation to place the activity toy on a level surface at least 2 m from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.
11. The activity toys shall be used over concrete, asphalt or any other hard surface. Do not use in soil that is not hard.
12. Consumers should not modify original activity toys without guidance from the manufacturer or a professional, especially to reduce the number of certain products.
13. This product is not for commercial use and will not carry any warranty for commercial use.


CLEANING INSTRUCTION

Use a soft sponge or cloth with some detergent to scrub the surface of products, and then dry the surface with dry cloth.


MAINTENANCE INSTRUCTIONS

- Regular inspection and maintenance of major components, without which the activity toys may tip over or become hazardous.
- Check the tightness regularly and tighten it according as required.
- Always check all plastic parts to avoid cracks or abrasion and make sure it is properly fixed when necessary.
- Replace defective parts in accordance with the manufacturer's instructions.


MOUNTING ACCESSORIES




Buffer plate *1




Slideway *1




Rails are each *2




Stickers *1 set




U-shaped side plate *2




2 ear platform *1




Aisle platform *1




Ferrule *4



Nose *2




Star baffle *1




Aisle side panel *2




Basketball *1




Aisle U-shaped side panel *2




Large side plate *1




Stair handrail *2




Type A baffle *2




Basketball net *1




Fold basketball hoop *1



Pedal *3



Telescope *1



Large nut *6



Flower nut *2



Square block screw *2



Rectangular block screw *2



Child prodigy Nut *32



Small cross nut *20




Screw *1




Plastic screwdriver *1


Installation Instructions




- 1 Assemble the buffer plate and slide




- 2 Fix the handrails on both sides of the slide




- 3 Assemble the 2 ear platform and star baffle




- 4 Fasten the assembled platform and type A baffles to the U-shaped side plate




- 5 Fix the assembled slide




- 6 Install the U-shaped side plate on the other side




- 7 Assemble Aisle U-shaped side panel and aisle platform




- 8 Insert Aisle side panel




- 9 Connect with the side part



- 10 Assemble stair handrails and pedals



- 11 Fasten the assembled stairs to the U-shaped side plate



- 12 Fix the U-shaped side plate to the other side of the aisle, and then install the basketball hoop, ferrule, telescope, and stick the sticker to complete the installation

NOTE: The installation of the basketball net is shown below:

