

Owner Manual

1. Daily Cleaning

- Dust with a soft, dry microfiber cloth
- For fingerprints or smudges, wipe lightly with a damp (not wet) cloth, then immediately buff dry
- Use only PH-neutral, wood-safe cleaners. Avoid ammonia, bleach or silicone-based polishes, they dull the low-sheen seal

2. Spill & Stain Care

- Blot liquids at once; do not rub
- If a ring appears, mix a drop of mild dish soap with water, dampen cloth, wipe in grain direction and dry
- For sticky residue, use a cloth dampened with a 50/50 mix of water and white vinegar, then dry

3. Heat & Moisture Protection

- Always set hot mugs, dishes and electronics on coasters or felt pads
- Do not leave cold glasses to "sweat" directly on the surface; prolonged moisture can ghost the finish
- Maintain indoor humidity between 35-55 % to minimise seasonal wood movement

4. Weekly / Monthly Maintenance

- Rotate decorative items so the finish ages evenly
- Check leg bolts every 3 months; tighten with the supplied Allen key until snug
- Apply a beeswax-based wood conditioner once a year to refresh lustre (test on underside first)

5. What to Avoid

- ✗ Abrasive pads, steel wool or magic-eraser sponges.
- ✗ Commercial glass cleaner, furniture wax sprays, or oil soaps.
- ✗ Direct sunlight for extended periods, use blinds or curtains to reduce UV fading.
- ✗ Dragging the table; lift when moving to protect leg joints.