








ASSEMBLY INSTRUCTION FOR

CHRISTOPHER NESTING END TABLE




Hardware List


1		Bolt	20x8mm	16
2		Bolt	16x6mm	2
3		Flat Washer	20x8mm	10
4		Allen Key	5mm	1
5		Allen Key	4mm	1




Step 1




Step 2




Step 3




Step 4




Step 5




Step 6



Step 7



Step 8



ASSEMBLY INSTRUCTION FOR CHRISTOPHER NESTING TABLE

Adjusting Floor Levelers & Hinges


Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

Step 1:- Adjust the Floor Levelers

Check for Stability – Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the Levelers – These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed – Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.



Adjustable Leveler