


Owner Manual



MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.


Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :


This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS



Installation:
40 minutes.



Two Person



Before You Start

Please follow the steps below:

-  Unbox the package and check if all parts and accessories are complete.
-  If you find something missing, stop assembly and contact your supplier immediately.
-  Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
-  NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.




Warranty

-  We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.
-  Are you having difficulty with assembly? Missing parts? Please send email with your order number
-  For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.

Exploded View



Parts List (Box A)

A ×1






Table Top

B ×2




Leg frame

C ×1



Support stretcher


×1



Hardware Pack


Parts List (Box B)

D ×1




Left frame

E ×1



Middle frame


F ×1



Right frame


Hardware List(Box A)

1 x 17+2



Ø1/4" *32mm bolt

2 x 4




Ø1/4" *28mm bolt

3 x 13+2




Ø1/4" spring washer

4 x 13+2




Ø1/4" *16*1.2mm Flat washer

5 x 8



Ø5/16" spring washer

6 x 1




Allen key

7 x 1




Driver screws

8 x 8+2




Wooden plug

9 x 2




cap

10 x 2



hanging rails

11 x 4





Ø3*12mm screw

ASSEMBLY INSTRUCTIONS




Step 1


Reverse the handle to the outside of part F/D using a screwdriver ⑦.



Step 2

Connect the leg frame B to the side frames D/ F with bolt ① ,spring washer ③/⑤ ,flat washer ④ , tight bolt with allen key ⑥ ,Then use wooden plug ⑧ to cover the holes.


①	 × 8	Ø1/4" *32mm
④	 × 4	Ø1/4" *16*1.2mm Flat washer
⑤	 × 4	Ø5/16"
③	 × 4	Ø1/4"
⑥	 × 1	Allen key
⑧	 × 4	Wooden plug



Step 3

Install the center frame E to the side frames D / F with bolt ② , spring washer ③ and flat washer ④ , tight bolt with allen key ⑥.


②	 × 4	Ø1/4" *28mm
④	 × 4	Ø1/4" *16*1.2mm Flat washer
③	 × 4	Ø1/4" spring washer
⑥	 × 1	Allen key



Step 4

Install the Support stretcher C to the three side frames D/E/F with bolt ①, spring washer ③ and flat washer ④, tight bolt with allen key ⑥.


①		× 5	Ø1/4" *32mm
④		× 5	Ø1/4" *16*1.2mm Flat washer
③		× 5	Ø1/4" spring washer
⑥		× 1	Allen key



Step 5

Install the table top A to the two leg frames B with bolt ①, spring washer ⑤, tight bolt with allen key ⑥, Then use wooden plug ⑧ to cover the holes.


①		× 4	Ø1/4" *32mm
⑤		× 4	Ø5/16" spring washer
⑥		× 1	Allen key
⑧		× 4	Wooden plug



Step 6

Open bottom drawer of part F, connect hanging rails ⑩ to top drawer with screw ⑪, the distance depend on you file size, then tight screw with screwdriver ⑦.


11	 × 4	Ø3*12MM screw
7	 × 1	Driver screws
10	 × 2	hanging rails



Step 7


Put the cap ⑨ into the hole as picture.

9	 × 2	cap
---	---	-----




Door Hinge Adjustment Instructions


Concealed hinges are three-way adjustable.




Horizontal by screw adjustment!




Concealed hinges are three-way adjustable.




In-and-out by loosening the hinge arm mounting screw or via cam adjustment!



Concealed hinges are three-way adjustable.




Vertical via slots in the mounting plate or via cam adjustment!




Slide Rail Installation Method

1. Slide out the tab.



2. Position the slide rod against the tab.



3. Push the drawer in.

