


Instruction



We kindly recommend that you check the quantity and condition of the panels and accessories upon receiving the product, as outlined in the instruction manual. If you find any missing parts, damages or encounter assembly issues, please feel free to contact us, and we will be happy to assist you within 24 hours.



WARNING!

Furniture tipping over can result in serious or fatal crush injuries. To mitigate the potential hazard of tipping, this product is equipped with an anti-tip device, the installation of which should be imperative in strict adherence to the provided instructions. We encourage you to reach out to us without hesitation should you require any explanations regarding this product or the accompanying anti-tip device.

Supplementary to the installation of restraints for the prevention of tip-overs, kindly observe the following guidelines:

1. Don't allow children to ascend or suspend themselves from furniture pieces, including drawers and cabinet doors.
2. Avoid placing televisions or other weighty objects atop this product.
3. Exercise caution by refraining from using the product as a platform for standing.

Furniture tipping over can result in serious or fatal crush injuries. To effectively mitigate the risk of furniture tipping over, please adhere to the following precautions:

- Ensure the installation of the supplied anti-tip device.
- Don't place televisions on this product.
- Exercise vigilance in preventing children from standing, climbing, or hanging on drawers, doors, or shelves.
- Avoid simultaneously opening multiple drawers.
- Distribute heavier items within the bottom drawer.
- Preserve the integrity of the drawer interlock system by refraining from damaging or removing it.

 WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover: ● ALWAYS install tipover restraint provided. ● NEVER put a TV on this product. ● NEVER allow children to stand, climb or hang on drawers, doors, or shelves. ● NEVER open more than one drawer at a time. ● Place heaviest items in the lowest drawers. ● Do not defeat or remove the drawer interlock system.
	<i>This is a permanent label. Do not remove!</i>



IMPORTANT INFORMATION

PLEASE READ CAREFULLY

KEEP THIS INFORMATION FOR FURTHER REFERENCE

GENERAL GUIDELINES

Please carefully read and follow the instructions provided below proper usage of this product. It is advised to retain this manual and pass it along if the product is transferred to another user. Please note that this summary might not cover all variations and details. For additional information and assistance, do not hesitate to get in touch with our professional customer service team.

NOTES











- Adhere closely to the assembly instructions and utilize the product solely for its intended purpose.
- If an odor is detected upon opening the package, allow the product to ventilate in a cool and well-ventilated area for several days.
- Prior to assembly, thoroughly inspect the product for any defects or missing components. If any issues are observed, avoid using the product to prevent potential damage or injury. Instead, reach out to us for assistance and replacement.
- To ensure safe usage, it is recommended that you periodically check the bolts and connections of the product.
- During assembly, choose a soft, flat, and clean surface to prevent scratching or damaging the product.
- We recommend having two individuals participate in the assembly of this product.

WARNINGS


- Throughout the assembly process, keep components and packaging materials out of reach of children and pets to avoid potential hazards such as injury or choking.
- Don't use sharp objects or corrosive substances that might harm the product.
- When unpacking the item, exercise caution to prevent pinching of metal joints, especially when children are present.

ANTI-TIP WARNING

- Furniture tipping over can result in serious or fatal crush injuries. To prevent this hazard, it is imperative to securely anchor the furniture to the wall using the provided anti-tip device.
- Different wall materials necessitate specific types of anti-tip devices. Failure to use the appropriate anti-tip device can lead to dangerous situations. For advice on suitable anti-tip devices, please consult your local specialist dealer.

① 	② 	③ 	④ 
2PCS	2PCS	2PCS	2PCS
⑤ 	⑥ 	⑦ 	⑧ 
2PCS	2PCS	2PCS	2PCS
⑨ 	⑩ 	⑪ 	
2PCS	2PCS	8PCS	

Before beginning installation, kindly inspect the package to ensure that all accessories are present and undamaged. If you identify any missing or damaged accessories, please do not hesitate to reach out to our dedicated customer service team. We are committed to promptly arranging replacements for any affected components.



Fittings

Please verify that you have all the listed accessories below:

NOTE: The quantities provided are sufficient to complete the assembly, and in some cases, there might be more accessories supplied than required.

Bag 1


ITEM	PART	QTY	ITEM	PART	QTY
A		24PCS	B		24PCS
C		12PCS	D		8PCS
E		1PC	F		8PCS
G		8PCS	H		4PCS
I		2PCS	J		10PCS
K		2PCS	M		2PCS
N		34PCS	O		4PCS
P		8PCS	Q		2PCS
S		8PCS			

Tools required




Phillips screwdriver
(small & medium)


step 1




step 2




step 3



step 4



step 5




Then push the slide rail back, fix the second and third screws at the front end of the slide rail Back.

X2


C	X4
	
M3.5x14mm	

step 6




Step 6 and 7 will be completed on the same board #4.

Note that the arrow pointing forward should be aligned with the curved side of board #4.




X2

Push the slide rail forward, and fix the first screw at the rear end of the slide rail(BACK).

O	X2
	

C	X2
	
M3.5x14mm	

step 7




Then push the slide rail back, fix the second and third screws at the front end of the slide rail.

X2

C	X4
	
M3.5x14mm	

step 8





X2

A	X8
	
M6x35mm	

M	X2
	

N	X2
	
M4x14mm	

step 9




X2

B	X8
	
Ø15x9mm	


G	X4
	
Ø8x30mm	

step 10



X2



step 11



X2

A	X8
	
M6x35mm	

step 12




X2


B	X8
	
Ø15x9mm	

G	X4
	
Ø8x30mm	


step 13



step 14




step 15




P	X8	D	X8
			
		M3x16mm	

step 16






K	X2	J	X2
			
Ø6x30mm		M4x35mm	

step 17



X2


step 18



X2

H	X4
	
M4x10mm	


step 19



X2

S	X8

step 20



Congratulations!!
You have successfully completed the assembly!