






Coffee table

User Manual




Warning : Please read this instruction manual carefully before using the product.

version: 2.0

Package Contents

Plates and iron components	Assembly tool kit	Instruction manual
----------------------------	-------------------	--------------------


Precautions




1.Avoid long-term direct sunlight exposure




2.Stay away from fire




3.keep away from sharp objects




4.Keep infants/children away from assembly parts to avoid choking and suffocation.




5.keep away from corrosive substances



6.Pay attention to avoid over-tightening fasteners, orthey may induce cracking within the board.



7.Prevent objects from being damaged by immersion in water




8.Prevent object collision and damage




9.Be careful to avoid collisions

Installation of Cams and Pins













Screw the pin into the hole. To set the cams correctly, ensure that the arrow on the cam is opening o the hole of the pin it is locking. Lock the cam by tturning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.




Disassembly Diagram



Parts List


1 	2 	3 
4 	5 	6 
7 	8 	9 
10  x 2	11 	12 
13 	14 	15  x 2

16




x 2


17




18




19




20




21




22



23




24










x 3

25





x 2

A Ø6x35MM  X60+3	B Ø15x10MM  X60+3	C Ø6x30MM  28+2	D Ø5x40MM  X4	E M5x20MM  X4
F  X4	G  X3+2	H  0.8M X1	I  X1	J M4x10MM  X4
K M4 M3  X1	L  X1	M  X2	N M5x10MM  X26+2	O  X4
P  X8	Q  X10			



ASSEMBLY INSTRUCTION

Step 1



A	x 24
	
Ø6x35mm	


Step 2




B	x 6
	
Ø15x10mm	



ASSEMBLY INSTRUCTION

Step 3



A	x 4
	
Ø6x35mm	

Step 4




B	x 2
	
Ø15x10mm	
C	x 2
	
Ø6x30mm	


ASSEMBLY INSTRUCTION

Step 5

Please pay attention to the hole orientation.




Step 6




ASSEMBLY INSTRUCTION

Step 7




Step 8




ASSEMBLY INSTRUCTION


Step 9



D	x 2
	
$\phi 5 \times 40\text{mm}$	
C	x 2
	
$\phi 6 \times 30\text{mm}$	



Step 10



A	x 8
	
$\phi 6 \times 35\text{mm}$	




ASSEMBLY INSTRUCTION

Step 11



B	x 8
	
$\phi 15 \times 10 \text{ mm}$	
C	x 4
	
$\phi 6 \times 30 \text{ mm}$	



Step 12



E	x 2
	
M5x20mm	
F	x 1
	
A	x 5
	
$\phi 6 \times 35 \text{ mm}$	





ASSEMBLY INSTRUCTION

Step 13



C	x 4
	
Ø6x30mm	

Step 14




B	x 6
	
Ø15x10mm	

ASSEMBLY INSTRUCTION

Step 15


The lamp belt passes through the hole.




G	x 3
	
H	x 1
	

ASSEMBLY INSTRUCTION

Step 16





A	x 4
	
ø6x35mm	

Step 17

Please pay attention
to the hole orientation.


The side with shorter
hole spacing is upward.



D	x 2
	
ø5 x 40mm	
C	x 2
	
ø6x30mm	



ASSEMBLY INSTRUCTION

Step 18



F	x 2
	
B	x 2
	
ø15x10mm	


Step 19




B	x 2
	
ø15x10mm	



ASSEMBLY INSTRUCTION

Step 20



A	x 4
	
Ø6x35mm	



Step 21



B	x 4
	
Ø15x10mm	
C	x 4
	
Ø6x30mm	


ASSEMBLY INSTRUCTION


Step 22



B	x 5
	
ø15x10mm	
C	x 2
	
ø6x30mm	


Step 23




F	x 1
	
E	x 2
	
M5x20mm	
A	x 11
	
ø6x35mm	

ASSEMBLY INSTRUCTION

Step 24




Step 25



ASSEMBLY INSTRUCTION


Step 26



B	x 4
	
ø15x10mm	

Step 27


x 2




M	x 2
	
J	x 4
	
M4x10mm	

ASSEMBLY INSTRUCTION

Step 28




Step 29



N	x 4
	
M5 x 10mm	

ASSEMBLY INSTRUCTION


Step 30



N	x 8
	
M5 x 10mm	

ASSEMBLY INSTRUCTION


Step 31



N	x 4
	
M5 x 10mm	

ASSEMBLY INSTRUCTION








Step 32



P	x 8
	

ASSEMBLY INSTRUCTION


Step 33



N	x 10
M5 x 10mm	
L	x 1
I	x 1


ASSEMBLY INSTRUCTION

Step 34



0	4
	


Step 35



Q	10
	


ASSEMBLY INSTRUCTION

Step 36



Note: Before You Open the top of Table No.1, you should raise table No.2 as a support, otherwise, table No.1 will be out of balance and the hinge position will be damaged!


It is forbidden to expand the No.1 slab after it is lowered.





3-years Warranty

We guarantee your product is free from defects in product material and workmanship for three(3) years starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, We will send the corresponding accessories, Replacement is free and all shipping costs are covered.



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us and we will get back to you within 24 hours
	Having issue(s) while reading the instruction or completing the assembly.	Feel free to contact us and we will get back to you within 24 hours.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it.We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Table Surface	Board Surface is broken, scratched or lack of some screw holes.	Feel free to contact us and we will get back to you within 24 hours.
	The screw holes on the wooden board and other wooden boards are not aligned.	1.Please tighten the screws on the board by 70%, do not tighten completely. 2. Adjust the wooden board and board.Until the holes are arranged neatly, then tighten all screws
	Desktop misalignment and unevenness	1.Please tighten the screws connecting the table board to the elevator by 70%, do not tighten them completely. 2.Adjust to a flat and aligned desktop, then tighten the screws. 3.If your problem still can't be solved, please feel free to contact us.
Metal accessories	Metal accessories are damaged, rusted, bent, and broken.	Feel free to contact us and we will get back to you within 24 hours.
	The table is unstable after being assembled.	1.Check if the screws are tightened. 2.Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3.If your problem still can't be solved, please feel free to contact us.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it.We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.