


Soji™ String Light Shades

Included:




Shade (5)

Durable DuPont™ Tyvek® material




Frame Support (5)

Prepare:




Use only LED bulbs to avoid overheating and protect shade fabric. Ensure all bulbs are tightened into their sockets before proceeding.

Instructions:




1. Position Frame Support

Spread frame support and clamp it around your string light cord or socket. Avoid clamping directly on the bulb.




2. Add Shade

Pass frame support through top and bottom shade openings. Shade top and bottom are identical.




3. Attach Shade Top

Capture the top frame support tabs in the shade rings, 2 tabs per side.



4. Attach Shade Bottom

Stretch shade down and capture bottom frame support tabs in the shade's bottom rings. This may take considerable force the first time since the DuPont™ Tyvek® fabric is intentionally tight to keep the shade looking crisp for years of all-season enjoyment.



5. Repeat

Add shades as desired such as every bulb, every other bulb, or more. Add elegance where you need it.

Helpful Tip

Shades are designed to be used inside and outside during all seasons. To prolong the life of your shades, store indoors when not in use.

THANK YOU FOR YOUR PURCHASE!

We want you to be completely satisfied. If you have any questions please contact our US-based customer service department
support@allsopgarden.com
800-426-4303

Love your product?
Follow and Tag us
@allsopgarden with #allsopgarden

